

Projector Service Manual

Model:
X1140A, X1240, X1140, P1340W, X1340WH,
H6510BD

Version: Rev6
First Edition (Apr. 2012)

RESTRICTIONS ON USE OF MATERIALS:
--

Index

REVISION LIST	3
CHAPTER 1 SYSTEM SPECIFICATION	4
Product Specification	4
System Block Diagram	21
Product Overview	23
CHAPTER 2 SYSTEM UTILITIES	27
Firmware Upgrade SOP	27
Method to Enter Factory Menu	39
EDID Upgrade SOP	40
Serial Number Upgrade SOP	44
CHAPTER 3 SYSTEM DISASSEMBLING AND REPLACEMENT	47
Main Unit Disassembling	47
Module Assembly Key Point - Optical Engine	52
Module Assembly Key Point - Mechanical	77
CHAPTER 4 TROUBLESHOOTING	93
System Analysis	93
Optical Problems Checking Items	94
Power Supply Problems Checking Flow	100
LED Messages Definition	103
Error Count Messages Definition	104
RS232 Connection	106
Adjustment / Alignment Procedure	108
CHAPTER 5 FRU LIST	113
Exploded Diagram	113
Module 1 – Total Exploded View	113
Module 2 – ASSY UPPER CASE	114
Module 3 – ASSY LOWER CASE	114
Module 4 – ASSY REAR CASE	115
FRU List	116
APPENDIX A - CODE LIST: IR / RS232 / DDC DATA	123
1. Remote Control Code	123
2. RS-232 Command Code	125
3. DDC Data	127
APPENDIX B – SCHEMATICS	130

Revision List

Version	Release Date	Revision History	Vendor Model Name
Rev0	2012.04.13	First Release	
Rev1	2012.05.07	Add X1240	
Rev2	2012.06.11	Add X1140	
Rev3	2012.08.03	Add P1340W	
Rev4	2012.11.13	Add H6510BD	
Rev5	2013.10.14	Add model name X1340WH	
Rev6	2013.10.23	Correct Chapter 1 System specification: 1.4.1 and 1.4.2 Light Leakage for H6510BD 2.1 Throw Ratio 2.2 Zoom Ratio 2.4 Projection Offset 15.3 Speaker	

Chapter 1 System Specification

Product Specification

- 1.0 Optical Performance
- 2.0 Image Quality
- 3.0 Mechanical Specification
- 4.0 Packaging
- 5.0 Thermal Specification
- 6.0 Environmental
- 7.0 Regulatory
- 8.0 Reliability
- 9.0 Power Requirements
- 10.0 Panel Specification
- 11.0 Compatibility
- 12.0 Image Interface
- 13.0 Control Interface
- 14.0 User Interface

1.0 Optical Performance	Tested under 60" (diagonal) image size with Wide projection lens position unless other specified.	
1.1 ANSI Brightness	X1140A/X1240/X1140/P1340W/X1340WH : Minimum 2160 Lumens Typical 2430 Lumens (For reference) H6510BD : Minimum 2400 Lumens Typical 2700 Lumens (For reference)	
1.2 Brightness Uniformity		
1.2.1 ANSI Uniformity	X1140A/X1240/X1140 : Minimum -45% P1340W/X1340WH/H6510BD : Minimum-50%	
1.2.2 JBMA Uniformity	X1140A/X1240/X1140 : Minimum 75% P1340W/X1340WH : Minimum 70% H6510BD : Minimum 65%	
1.2.3 Upper-Down unbalance	0.5~2	
1.2.4 Left-Right unbalance	0.6~1.67	
1.3 Contrast Ratio		
1.3.1 ANSI Contrast	Minimum 150:1	
1.3.2 FOFO Contrast without APM	Minimum 2000:1	
1.3.3 FOFO Contrast with APM	X1140A/X1240/X1140/P1340W/X1340WH : Minimum 8000:1 Typical 10000:1 (For reference) H6510BD : Minimum 6000:1 Typical 7500:1 (For reference)	
1.4 Light Leakage		
1.4.1 Light Leakage in Active Area	X1140A/X1240/X1140 : <0.5 lux compared to center point within 60" (Diagonal at 2.3m, Wide) image size. P1340W/X1340WH/H6510BD : <0.5 lux compared to center point within 60" (Diagonal at 1.9m, Wide) image size. H6510BD: <0.5 lux compared to center point within 60" (Diagonal at 1.53m, Wide) image size. Note: This light leakage in Active area is only described as the spot light with obvious shape. It is not included the uniformity difference of the projector for black pattern.	
1.4.2 Light Leakage out of Active Area (Except DMD Defect)	X1140A/X1240/X1140 : <0.5 lux with 60"~80"(Diagonal at 2.3m, Wide) image size P1340W/X1340WH/H6510BD : <0.5 lux with 60"~80"(Diagonal at 1.9m, Wide) image size H6510BD: <0.5 lux with 60"~80"(Diagonal at 1.53m, Wide) image size	
1.5 Color	Reference meter: Vendor Lab CS1000 Spectroradio Meter (S/N: 00370975) (Spec will be confirmed at PVT stage) C/W angle : R83Y45W52C35B64G81	
	X	Y
1.5.1 White	0.308±0.04	0.369±0.04
1.5.2 Red	0.646±0.04	0.340±0.04
1.5.3 Green	0.309±0.04	0.616±0.04
1.5.4 Blue	0.146±0.03	0.053±0.03
1.6 Color Uniformity	ΔX	ΔY

1.6.1 White	0.040	0.040	
1.6.2 Red	0.040	0.040	
1.6.3 Green	0.040	0.040	
1.6.4 Blue	0.040	0.040	
1.7 Color Gamut	Typ 70% compare NTSC		
1.8 WBA Criterion for Standard mode	1. X1140A/X1240/X1140 : PC source White Color is (0.313+/-0.006, 0.326+/-0.006). P1340W/X1340WH/H6510BD : PC source White Color is (0.313+/-0.006, 0.324+/-0.006). 2. Typ~70% Brightness compare with Bright mode for reference.		
2.0 Image Quality			
2.1 Throw Ratio	X1140A/X1240/X1140 : 53"±3% @ 2m (1.86~2.04) Wide P1340W/X1340WH : 62"±3% @ 2m (1.5~1.65) Wide H6510BD : 78.3"±3% @ 2m (1.15~1.5) Wide		
2.2 Zoom Ratio (tolerance applied)	X1140A/X1240/X1140/P1340W/X1340WH : 1.1±2% H6510BD : 1.3±2%		
2.3 Distortion			
2.3.1 Keystone Distortion	<1.0%		
2.3.2 Vertical TV Distortion	<1.0%		
2.4 Projection Offset	X1140A/X1240/X1140 : 120% ±5% P1340W/X1340WH : 100% ±5% H6510BD : 110+/-5%		
2.5 Focus Range			
2.5.1 Visible Range	1~8 m		
2.5.2 Clearly Focus Range	1.5~6 m(Spec. defined as item 2.6)		
2.6 Focus			
2.6.1 ☒ Pattern	(1) If pattern can be uniformly focused (not worse than Limit Sample), then pass! Limit Sample: Mercury Projector, S/N: 282596-00128 (2) If it's difficult to judge, then check 2.6.2		
2.6.2 Defocus and Flare	Defocus: R<=3.5; G<=3.0; B<=3.0 pixel Flare: R<=4.0; G<=4.0; B<=4.0 pixel Slight flare is not counted as flare.		
2.6.3 Focus unbalance	Adjust focus from near to far until one corner clear, difference less than 50 cm		
2.7 Lateral Color		Center of 49"diagonal area	All other area
	R-G	<2/3	<1
	G-B	<2/3	<1
	R-B	<1	<1
2.8 Image Quality			
2.8.1 DMD Image Quality			
2.8.2 Image Imperfection			
2.9 Lamp Type	X1140A/X1240/X1140/P1340W/X1340WH : 190W Osram (P-VIP 180W 0.8 E20.8) H6510BD : Osram 210w (P-VIP 210/0.8/E20.9n)		
3.0 Mechanical Specification			
3.1 Dimensions	264 x 220 x 78.4 mm (W x D x H)		

3.2 Weight	X1140A/X1240/X1140/H6510BD : <2000g P1340W/X1340WH : <2200g	
3.3 Security Slot	>36 Kg	
3.4 Lens Cover	N/A	
3.5 Feet	Fast adjustable foot in front, Adjustable foot and Fixed foot in rear. Foot Tilt:0-6° ,right/left: +2.2° /-0.5°	
3.6 Appearance	Follow packing section	
4.0 Packaging	Detail refer to Packing Description	
4.1 Outside Dimensions	360 * 160 * 297 mm (L * W * H)	
4.2 Weight	X1140A/X1240/X1140/P1340W/X1340WH/H6510BD : < 3.3 kg (Including Accessories, Projector)	
4.3 Transportation	42 EA by Air; 3136 EA @ 40' container, or 1372 EA @ 20' container by Sea	
5.0 Thermal Specification	Mechanical component temperature at ambience 0~40°C	
5.1 Surface held or touched for short periods	Metal	Plastic
	<60°C	<85°C
5.2 Surface which may be touched	Metal	Plastic
	<70°C	<95°C
5.3 Exhaust Air	<95°C	
5.4 Overheat protection	Overheat protection auto shutdown must work properly by 47±2°C ambient temperature	
5.5 Fan Numbers	Lamp Fan: #1 70x70x25mm x 1pcs Blower Fan: #2 50x50x20mm x 1pcs	
6.0 Environmental		
6.1 Temperature	Operating	0~40°C, without condensation
	Storage	-30~65°C, without condensation
6.2 Humidity	Operating	10~90%RH, without condensation
	Storage	10~90%RH, without condensation
6.3 Audible Noise Level	Typical	X1140A/X1240/X1140/P1340W/X1340WH : Normal mode: 33dBA @ 23±2°C, CW x2 speed Eco mode: 29dBA @ 23±2°C, CW x2 speed Normal mode: 35dBA @ 23±2°C, CW x3 speed Eco mode: 31dBA @ 23±2°C, CW x3 speed H6510BD : Normal mode: 35dBA @ 23±2°C, CW x2 speed Eco mode: 29dBA @ 23±2°C, CW x2 speed Normal mode: 37dBA @ 23±2°C, CW x3 speed Eco mode: 31dBA @ 23±2°C, CW x3 speed
	Maximum	X1140A/X1240/X1140/P1340W/X1340WH : Normal mode: 35dBA @ 23±2°C, CW x2 speed Eco mode: 31dBA @ 23±2°C, CW x2 speed Normal mode: 37dBA @ 23±2°C, CW x3 speed Eco mode: 33dBA @ 23±2°C, CW x3 speed H6510BD : Normal mode: 37dBA @ 23±2°C, CW x2 speed Eco mode: 31dBA @ 23±2°C, CW x2 speed Normal mode: 39dBA @ 23±2°C, CW x3 speed Eco mode: 33dBA @ 23±2°C, CW x3 speed

6.4 Altitude	Operating: 1. 12,000 feet @ 25 °C (3.5 hours) 2. Altitude Ramp rate: <= 3500 feet per minute (1 hour) Non-operating: 40,000 feet @ -30 °C (1 hour)	
6.5 Shock		
6.6 Drop		
6.7 Vibration		
7.0 Regulatory	Safety	CB, GS, UL,CCC, CECP *PSE: Customer apply by themselves
	EMC	CE, FCC, VCCI
	ESD	
8.0 Reliability		
8.1 MTBF	25000 hours at 35 °C (except Lamp)	
8.2 Lamp Lifetime	Normal : 4500 hours Eco: X1140A/X1240/X1140/P1340W/X1340WH : 6000 hours, H6510BD : 5000 hours. Dynamic Eco : 7000 hours (Dynamic dimming + Extreme dimming) (50% of Projector will have 50% initial minimum brightness)	
9.0 Power Requirements		
9.1 Power Supply (Normal)	VAC 100 – 240 (50/60Hz),	
9.2 Power consumption	Typical	X1140A/X1240/X1140/P1340W/X1340WH : 240W @ 100VAC~240VAC H6510BD : 270W @ 100VAC~240VAC
	Max.	X1140A/X1240/X1140/P1340W/X1340WH : 250W @ 100VAC~240VAC H6510BD : 290W @ 100VAC~240VAC
	Standby	0.5W Max. at 100~240VAC (VGA out loop through is disabled)
9.3 Power Connector	IEC60320C14	
10.0 Panel Specification		
10.1 Type	X1140A/X1240/X1140 : 0.55" SVGA 2xLVDS Series 450 DMD P1340W/X1340WH : 0.65" WXGA, 1280x800 H6510BD : 0.65" 1080p 2xLVDS S600 DMD	
10.2 Pixels	X1140A/X1140 : H: 800 X V: 600 X1240 : H: 1024 X V: 768 P1340W/X1340WH : H: 1280 X V: 800 H6510BD : H: 1920 X V: 1080	
10.3 Color Depth	30 Bits (1.07 Billion Colors)	
11.0 Compatibility		
11.1 PC	X1140A/X1240/X1140 : PC Compatible 640X480 → 800X600, compressed 1600X1200; Sync-on-Green (For Mac Timing Only) P1340W/X1340WH : PC Compatible 640X480 → 1280X800, compressed to 1900X1200 (60Hz Reduce Blanking); Sync-on-Green (For Mac Timing Only) H6510BD : PC Compatible 640X480 → 1920X1080, compressed to 1900X1200 (60Hz Reduce Blanking); Sync-on-Green (For Mac Timing Only)	

11.2 Video	NTSC/ NTSC4.43/ PAL (Including PAL-M, PAL-N)/ SECAM/ PAL60/
11.3 YpbPr	NTSC (480i)/ 480p/ PAL (576i)/ 576p, HDTV (720p/1080i/1080p)
11.4 DDC	EDID 1.3
12.0 Image Interface	
12.1 Analog RGB Input	X1140/H6510BD : 15 pin D-Sub (Female) x 1 X1140A/X1240/P1340W/X1340WH : 15 pin D-Sub (Female) x 2 G(Y): Video amplitude 0.7/1.0 V _{p-p} : Impedance 75Ω RB(CbCr): Video amplitude 0.7 V _{p-p} : Impedance 75Ω HD/VD/CS: TTL Level
12.2 Video Input	RCA jack (Yellow) Video amplitude 1.0 V _{p-p} : Impedance 75Ω
12.3 S-Video Input	4 pin Mini-Din (Female) Y: Luminance amplitude 1.0 V _{p-p} : Impedance 75Ω C: Chroma amplitude 0.286 V _{p-p} : Impedance 75Ω
12.4 YpbPr Input	X1140 : 15 pin D-Sub (Female) x 1 X1140A/X1240/P1340W/X1340WH : 15 pin D-Sub (Female) x 2 H6510BD : RCA jack (R G B) x 1 Y: Luminance amplitude 1.0 V _{p-p} : Impedance 75Ω PbPr/C _b Cr: Chroma amplitude 0.7 V _{p-p} : Impedance 75Ω
12.5 Analog RGB Output	X1140 : NA X1140A/X1240/P1340W/X1340WH/H6510BD : 15 pin D-Sub (Female) x 1 (Only support D-sub 1) G(Y): Video amplitude 0.7/1.0 V _{p-p} : Impedance 75Ω RB(CbCr): Video amplitude 0.7 V _{p-p} : Impedance 75Ω HD/VD/CS: TTL Level
12.6 HDMI Input	X1140A/X1240/X1140 : N/A P1340W/X1340WH/H6510BD : 1. 19 pin HDMI connector x 1 2. HDMI V1.4/HDCP/EDID V1.3 3. HDMI-Video/audio and HDMI-Graphic Signal 4. HDMI-Graphic Signal resolution is up to 1600x1200@60Hz 5. Down-mix 5.1channel to stereo channels
13.0 Control Interface	
13.1 IR Receiver	IR Receiver x 1 (Front) Angle: ±0° Distance 0~10m ; ±40° Distance 0~8m
13.2 Serial Connector	RS232 interface, D-Sub 9pin (Male type), command table adhere to Appendix A
13.3 USB Connector	Mini Type B x 1 Terminal for page up/down & Firmware download
14.0 User Interface	
14.1 Operator Keypad	9 Keys: Power ; Source ; Resync ; e ; Menu ; Left ; Right ; Up(Keystone+) ; Down(Keystone-)
14.2 Indicators	3 LEDs: Power On/Off Status; Lamp Status; Temperature Status
14.3 Electric Keystone	1. X1140/H6510BD : Manual vertical keystone and

	adjustable range ± 40 X1140A/X1240/P1340W/X1340WH : Auto and Manual vertical keystone and adjustable range ± 40 2. When CC enable and aspect ratio 16:9, keystone range $\pm 38^\circ$
14.4 Auto Ceiling mount detection	X1140A/X1240/X1140/P1340W/X1340WH : Projector will auto-detect and project by aligned screen like auto-keystone effect no matter which projection method (Front, Rear) H6510BD : N/A
14.5 Digital Zoom	Digital zoom 2X (X1140A/X1240/X1140 : 120Hz 3D on, Digital Zoom 1.8X) (P1340W/X1340WH/H6510BD : 3D on, Digital Zoom 1.4X)
14.6 Language	X1140A/X1240/X1140/H6510BD : English, Germany, Spanish, French, Italian, Portuguese, 中文 (繁), 中文 (簡), Russian, Polish, Thai, Dutch, Czech, Danish, Swedish, Hungarian, Turkish, Japanese, Korean, Vietnamese, Arabic (total 21 languages) P1340W/X1340WH : English, Germany, Spanish, French, Italian, Portuguese, 中文 (繁), 中文 (簡), Russian, Polish Thai, Dutch, Czech, Danish, Swedish, Hungarian, Turkish, Japanese, Korean, Vietnamese, Arabic (16 languages, total 21 languages in two groups)
15.0 Audio	
15.1 PC Audio Input	X1140 : NA X1140A/X1240/P1340W/X1340WH/H6510BD : $\Phi 3.5\text{mm}$ stereo mini jack 500mVrms 10 K Ω or more
15.2 Audio output	X1140 : NA X1140A/X1240/P1340W/X1340WH/H6510BD : $\Phi 3.5\text{mm}$ stereo mini jack
15.3 Speaker	X1140 : NA X1140A/X1240/P1340W/X1340WH : Speaker 8 Ω 2W X 1, Amplifier 1W X1 H6510BD : Speaker 4 Ω 2W X 1, Amplifier 1.5W X1
16.0 Lamp hour	X1140A/X1240/X1140/P1340W/X1340WH : Lamp hour = [Hour used in Normal Mode] + 4.5/6 *[Hour used in Eco. Mode] + 4.5/7 *[Hour used in Dynamic Eco Mode] H6510BD : Lamp hour = [Hour used in Normal Mode] + 4/5 *[Hour used in Eco. Mode] + 4/7 *[Hour used in Dynamic Eco Mode]
17.0 Closed Caption (CC)	
17.1 CC version	CC1/CC2/CC3/CC4
18.0 Instant On	Yes
19.0 3D Projection	X1140A/X1240/X1140 : 1. Support DLP 3D PC source 100/120Hz 2. VGA support timing: 640x480, 800x600, 1024x768 @100/120Hz

	P1340W/X1340WH/H6510BD : 1. Support DLP 3D PC source 50/60/100/120Hz and Video source 50/60Hz 2. VGA and HDMI(PC) support timing : 640x480, 800x600, 1024x768, 1280x800@50/60/100/120Hz 3. Video, S-Video, Component and HDMI(Video) support timing : HQFS 3D (480i@60Hz), 576i@50Hz 4. HDMI(Video) support timing : (1) HQFS 3D (480i@60Hz) , 576i@50Hz (2) HDMI 1.4a mandatory : Frame Packing (1080p@23.98/24Hz, 720p@50/60Hz) Side-by-Side Horizontal (1080i@50/60Hz) Top-and-Bottom (720p@50/60Hz, 1080p@23.97/24Hz)
20.0 Smart Source Detection	
21.0 Color Safe II	1. Projectors can compensate the color distortion due to the performance decay of lamp, color wheel, or some system components 2. The digital gains are apply on HSG WR, WG, and WB components with time pass, the digital gains are defined as color safe gain table with time (hours) 3. The color safe gain table will be released while the lamp life data reach 1000 hours and color safe function will implement at the same time
22.0 Dynamic Eco	1. Mode set up: Extreme dimming mode and Dynamic dimming mode 2. Advantage: (1) Enhance dynamic image contrast (2) Energy can be saved during content with dark scenes in dynamic dimming mode 3. Behavior: (1) Extreme dimming: Projector lamp power is decreased to ~30% of normal mode. When project is set to extreme dimming mode, which can be operated by the cycle lamp power 30% during 30 minutes and automatic recovery to eco mode 5~7 minutes. Projector lamp power come back to normal / eco mode within 5 sec. whenever projector is set to normal / eco mode. (2) Dynamic dimming: Frame-by-frame power adaption 100%~70% base on dark scene.

3D Projection:

- **For X1140A/X1240/X1140:**

(1) This function is only for 3D contents and must wear 3D glasses.

TI DDP DDP2431
● Can support 120Hz 3D source from PC

(2) 3D Function Detail Description :

- 3D: DLP 3D, off. Default is Off.
- DLP 3D
 - Select this item while using DLP 3D glasses, quad buffer (NVIDIA/ATI...) graphics card.
- “3D Sync Invert” is adjustable when above “3D” is on. Otherwise gray out. When you discover the inversion of the image depth (for your Left/Right eyes), do the invert action to solve this condition.
 - 3D Sync Invert only enable for DLP 3D, otherwise it will be gray out
 - When 3D is enabled, Display Mode and Color temperature (in Color Page) is not adjustable.
- Function disable :
 - When meeting 120Hz (no matter 3D on or off, HSG only one set value), if end user adjust adjustable items (ex. brightness) , the value will not be stored and only for that use only.
- If non-3D mode (120Hz), keep normal/same brightness.
- 3D function can be opened when 100/120Hz for PC source.
- Refresh rate change to not supported 3D timings under 3D mode, please show warning message of **"Input Not Supported under 3D mode"**, to enforce user to change back.
- 3D Warning message
 - When 3D is enabled, this screen will appear after exit OSD menu.
 - It shows only once of that source after power on. (one source one time only)
 - Show it while switching to another source which is set as 3D on and the message was not shown in that source after power on. Not show it while timing changes. (or adjust to off 3D Warning message)
 - Priority: PWD login screen (Security fn is on) → Lamp life reminder → 3D reminder Screen → Timer and other OSD pup-up fn.
 - Pop-up screen and appear 10 sec in the center of the screen. End-users can press Menu to exit within 10 sec.
 - Turn On/Off 3D warning message mechanism. Add one function item in OSD menu.
 - Reminder screen

Note: 3D display is now enabled.
1. Please make sure you have the correct 3D signals and glasses.
2. Please remember to turn off 3D if you don't want to see 3D images.
3. If the 3D display isn't correct, please try to enable 3D Sync Invert.
4. Display mode options will be disabled while in 3D mode.

● **For P1340W/X1340WH/H6510BD :**

(1) This function is only for 3D contents and must wear 3D glasses.

TI DDP DDP2431
Support FRC (Frame Rate Conversion) Can support HQFS 60Hz 3D source from DVD which need to go thru FRC Can support 120Hz 3D source from PC

(2) 3D Function Detail Description :

- 3D : DLP 3D, off. Default is Off.
- DLP 3D
 - Select this item while using DLP 3D glasses, quad buffer (NVIDIA/ATI...) graphics card and HQFS format file or DVD with corresponding SW player.
- “3D Sync **Invert**” is adjustable when above “3D” is on. Otherwise gray out. When you discover the inversion of the image depth (for your Left/Right eyes), do the invert action to solve this condition.
 - 3D Sync **Invert** only enable for DLP 3D, otherwise it will be gray out
 - When 3D is enabled, Display Mode and Color temperature (in Color Page) is not adjustable.
- Function disable :
 - When meeting 60/120Hz (no matter 3D on or off, HSG only one set value), if end user adjust adjustable items (ex. brightness), the value will not been stored and only for that use only.
- If non-3D mode (120Hz), keep normal/same brightness.
- 3D function can be opened when 50/60Hz for Video source and 100/120Hz for PC source.
- Refresh rate change to not supported 3D timings under 3D mode, please show warning message of “**Input Not Supported under 3D mode**”, to enforce user to change back.
- 3D Warning message
 - When 3D is enabled, this screen will appear after exit OSD menu.
 - It shows only once of that source after power on. (one source one time only)
 - Show it while switching to another source which is set as 3D on and the message was not shown in that source after power on. Not show it while timing changes. (or adjust to off 3D Warning message)
 - Priority : PWD login screen (Security fn is on) -> Lamp life reminder -> 3D reminder Screen -> Timer and other OSD pup-up fn.
 - Pop-up screen and appear 10 sec in the center of the screen. End-users can press Menu to exit within 10 sec.
 - Turn On/Off 3D warning message mechanism. Add one function item in OSD menu.
 - Reminder screen

Note: 3D display is now enabled.
1. Please make sure you have the correct 3D signals and glasses.
2. Remember to turn 3D off if you don't want to see 3D images.
3. If the 3D display isn't correct, please try to enable 3D Sync Invert.
4. Display mode options will be disabled while in 3D mode.

Electrical Specification

1. Timing Table

The PC timing is as following:

Resolution	Mode	Refresh rate (Hz)	H-frequency (kHz)	Clock (MHz)
640 x 480	VGA_60	59.940	31.469	25.175
	VGA_72	72.809	37.861	31.500
	VGA_75	75.000	37.500	31.500
	VGA_85	85.008	43.269	36.000
	VGA_120	119.518	61.910	52.500
800 x 600	SVGA_56	56.250	35.156	36.000
	SVGA_60	60.317	37.879	40.000
	SVGA_72	72.188	48.077	50.000
	SVGA_75	75.000	46.875	49.500
	SVGA_85	85.061	53.674	56.250
1024 x 768	SVGA_120	119.854	77.425	83.000
	XGA_60	60.004	48.363	65.000
	XGA_70	70.069	56.476	75.000
	XGA_75	75.029	60.023	78.750
	XGA_85	84.997	68.677	94.500
1152 x 864	XGA_120	119.804	98.958	137.750
	SXGA_70	70.012	63.851	94.500
1152 x 864	SXGA_75	75.000	67.500	108.000
1280 x 1024	SXGA_85	84.990	77.094	121.500
	SXGA_60	60.020	63.981	108.000
	SXGA_72	72.000	76.970	134.600
	SXGA_75	75.025	79.976	135.000
1280 x 960	SXGA_85	85.024	91.146	157.500
	QuadVGA_60	60.000	60.000	108.000
1400 x 1050	QuadVGA_75	75.000	75.000	126.000
1600 x 1200	SXGA+_60	59.978	65.317	121.750
640x480@60Hz	UXGA_60	60.000	75.000	162.000
640x480@67Hz	Mac G4	59.940	31.469	25.170
800x600@60Hz	MAC13	66.667	35.000	30.240
1024x768@60Hz	Mac G4	60.317	37.879	40.000
1024x768@75Hz	Mac G4	60.004	48.363	65.000
1152x870@75Hz	MAC19	75.020	60.241	80.000
1280 x 768	MAC21	75.061	68.681	100.00
	WXGA_60	59.870	47.776	79.500
	WXGA_75	74.893	60.289	102.250
1280 x 720	WXGA_85	84.837	68.633	117.500
1280 x 800	WXGA_60	60.000	45.000	74.250
1280 x 800 (for P1340W/X1340WH/ H6510BD)	WXGA_60	59.810	49.702	83.500
1440 x 900	WXGA_120	119.909	101.563	146.25
1680 x 1050	WXGA+_60	59.887	55.935	106.500
1920 x 1080	1680x1050_60	59.954	65.290	146.250
1920 x 1080	1920x1080-RB	60.000	66.600	138.500
1920 x 1080	1920x1080-EIA	60.000	67.500	148.500
1366 x 768	acer_16:9	59.790	47.712	85.500
1024 x 600	acer_timing	60.000	37.500	50.400
1920 x 1200 (for P1340W/X1340WH/ H6510BD)	1920x1200-RB	59.950	74.038	154.000

YPbPr support timing is as following:

Signal format	fh(kHz)	fv(Hz)
480i(525i)@60Hz	15.73	59.94
480p(525p)@60Hz	31.47	59.94
576i(625i)@50Hz	15.63	50.00
576p(625p)@50Hz	31.25	50.00
720p(750p)@60Hz	45.00	60.00
720p(750p)@50Hz	37.50	50.00
1080i(1125i)@60Hz	33.75	60.00
1080i(1125i)@50Hz	28.13	50.00
1080P@60HZ	67.5	60.00
1080P@50Hz	56.26	50.00
1080P@24Hz	27.00	24.00
1080P@23.98Hz	26.97	23.98

Video, S-Video support timing is as following:

Video mode	fh(kHz)	fv(Hz)	fsc(MHz)
NTSC	15.73	60	3.58
PAL	15.63	50	4.43
SECAM	15.63	50	4.25 or 4.41
PAL-M	15.73	60	3.58
PAL-N	15.63	50	3.58
PAL-60	15.73	60	4.43
NTSC4.43	15.73	60	4.43

The DVI_D & HDMI (HDCP) Established timing is as following: (for P1340W/X1340WH/H6510BD)

Resolution	Mode	Refresh rate(Hz)	H-frequency(kHz)	Clock(MHz)
640 x 480	VGA_60	59.940	31.469	25.175
	VGA_72	72.809	37.861	31.500
	VGA_75	75.000	37.500	31.500
	VGA_85	85.008	43.269	36.000
	VGA_120	119.518	61.910	52.500
800 x 600	SVGA_56	56.250	35.156	36.000
	SVGA_60	60.317	37.879	40.000
	SVGA_72	72.188	48.077	50.000
	SVGA_75	75.000	46.875	49.500
	SVGA_85	85.061	53.674	56.250
	SVGA_120	119.854	77.425	83.000
1024 x 768	XGA_60	60.004	48.363	65.000
	XGA_70	70.069	56.476	75.000
	XGA_75	75.029	60.023	78.750
	XGA_120	119.804	98.958	137.750
1152 x 864	SXGA_75	75.000	67.500	108.000
	SXGA_85	84.990	77.094	121.500
1280 x 1024	SXGA_60	60.020	63.981	108.000
	SXGA_72	72.000	76.970	134.600
	SXGA_75	75.025	79.976	135.000
	SXGA_85	85.024	91.146	157.500
1280 x 960	QuadVGA_75	75.000	75.000	126.000
1400 x 1050	SXGA+_60	59.978	65.317	121.750
1600 x 1200	UXGA_60	60.000	75.000	162.000
640x480@60Hz	Mac G4	59.940	31.469	25.170
640x480@67Hz	MAC13	66.667	35.000	30.240
800x600@60Hz	Mac G4	60.317	37.879	40.000

1024x768@60Hz	Mac G4	60.004	48.363	65.000
1024x768@75Hz	MAC19	75.020	60.241	80.000
1152x870@75Hz	MAC21	75.061	68.681	100.00
1280 x 768	WXGA_60	59.870	47.776	79.500
	WXGA_75	74.893	60.289	102.250
	WXGA_85	84.837	68.633	117.500
1280 x 720	WXGA_60	60.000	45.000	74.250
1280 x 800	WXGA_60	59.810	49.702	83.500
1280 x 800	WXGA_120	119.909	101.563	146.25
1440 x 900	WXGA+_60	59.887	55.935	106.500
1680 x 1050	1680x1050_60	59.954	65.290	146.250
1366 x 768	acer_16:9	59.790	47.712	85.500
1920 x1080	1920x1080_RB	60.000	66.587	138.500
1920 x1080	1920x1080_EIA	60.000	67.500	148.500
1024 x 600	acer_timing	60.000	37.500	50.400
1920 x 1200	1920x1200-RB	59.950	74.038	154.000
Vedio(HDMI)	480i	60	15.73	27.000
	480p	60	31.47	27
	576i	50	15.63	27.000
	576p	50	31.25	27.000
	720p_60	60	45.00	74.25
	720p_50	50	37.50	74.25
	1080i_60	60	33.75	74.25
	1080i_50	50	28.13	74.25
	1080p	60	67.5	148.5
	1080p	50	56.26	148.5
	1080p	24	27.00	74.25
	1080p	23.98	26.97	74.175

Characteristics of inputs/outputs


Signal	Parameter	Min	Type	Max	
RDATA	Impedance		75		Ohm
GDATA	Amplitude		0.7		Volts peak-to-peak
BDATA	Black pedestal		0		Volts
	Pixel Clock		165		M Hz
GDATA_SOG	Impedance		75		Ohm
	Amplitude		1		Volts peak-to-peak
	Video amplitude		0.7		Volts peak-to-peak
	Sync amplitude		0.3		Volts peak-to-peak
	Black pedestal		0		Volts
	Pixel Clock		165		M Hz
HDATA	Impedance		1		K ohm
	Amplitude, low level	0		0.8	Volt
	Amplitude, high level	2.5		5	Volt
	Frequency	31		99	K Hz
VDATA	Impedance		1		K ohm
	Amplitude, low level	0		0.8	Volt
	Amplitude, high level	2.5		5	Volt
	Frequency	48		120	Hz
SDADATA	Amplitude, low level	0		0.8	Volt
	Amplitude, high level	3		5	Volt
SCLDATA	Amplitude, low level	0		0.8	Volt
	Amplitude, high level	3		5	Volt
RXD	Amplitude	-25		25	Volt
TXD	Amplitude	-13.2		13.2	Volt

CVBS Luminance	Amplitude, total (video+ sync)		1		Volts peak to peak
	Amplitude, video		0.7		Volts peak to peak
	Amplitude, sync		0.3		Volts peak to peak
	Impedance		75		ohm
CVBS Chroma	Amplitude		700		m Volts peak to peak
	Impedance		75		ohm
Audio (for X1140A/X1240/ P1340W/X1340WH/ H6510BD)	Impedance (audio in)		10		K ohm
	Amplitude (audio in)	0		500	m Volt rms
	Bandwidth	300Hz		16kHz	
	S/N Ratio	40			dB
	Total Harmonic Distortion			10	%

1. Electrical Interface Character


Interface Definition :

- 15 pin definition of the mini D-sub male for DDC2B protocol




Pin	Definition	Pin	Definition	Pin	Definition	Pin	Definition	Pin	Definition
1	Red (Pr)	2	Green (Y)	3	Blue (Pb)	4	NC	5	NC
6	Red return	7	Green return	8	Blue return	9	DDCP 5V	10	GND
11	GND	12	SDA	13	H-sync	14	V-sync	15	SCL

- Video Input




Pin	Definition
1	Composite video input

- S-Video input




Pin	Definition
1	GND
2	GND
3	Luminance
4	Chroma

- RS232 Control Port




Pin	Definition	Pin	Definition
1	NC	2	RX
3	TX	4	NC
5	GND	6	NC
7	RTSZ	8	CTSZ
9	NC		

- Mini USB TYPE B



Pin	Definition
1	Vbus
2	D-
3	D+
4	ID
5	GND

- HDMI/DVI Input (for P1340W/X1340WH/H6510BD)



Pin	Signal
1	TMDS Data2+
2	TMDS Data2 Shield
3	TMDS Data2-
4	TMDS Data1+
5	TMDS Data1 Shield
6	TMDS Data1-
7	TMDS Data0+
8	TMDS Data0 Shield
9	TMDS Data0-
10	TMDS Clock+
11	TMDS Clock Shield
12	TMDS Clock-
13	CEC
14	Reserved (N.C. on device)
15	SCL
16	SDA
17	DDC/CEC Ground
18	+5 V Power (max 50 mA)
19	Hot Plug Detect

3. Functionality

External Message indicator

Message	Occasion
D-sub /Composite Video /S-Video Searching	The system does not detect the signal
Input Not Supported	The signal is over the specification
Lamp is approaching the end of its useful life in full power operation. Replacement suggested!	X1140A/X1240/X1140/P1340W/X1340WH : Lamp Hour is at 4470 hours H6510BD : Lamp Hour is at 3970 hours

Power Supply Specification

1. Input Power Specification

Specification	Description
Input Voltage Range	The unit shall meet all the operating requirements with the range 90 ~ 264 VAC
Frequency Range	The unit shall meet all the operating requirements with an input frequency range 47 Hz ~ 63 Hz
Power Consumption	X1140A/X1240/X1140 : Normal operation: 250W (Max) P1340W/X1340WH : Normal operation: 285W (Max) H6510BD : Normal operation: 290W (Max) standby mode: < 0.5W (VGA out loop through, LAN control, audio out are disabled), at 100~240VAC
Regulation Efficiency	85 % (typical) measuring at 115Vac and full load

1. Output Power Requirement

The power supply can provide DC 12V output as below :

NO.	Voltage	Regulation	Load Current Range	Ripple & Noise
1	+12 V	±10 %	0 A ~ 2 A	120mV/240 mV
2	+3.3 V	±5 %	0.04 A ~ 0.15 A	40mV/120 mV

The power supply can provide DC 380V output as below :

NO.	Voltage	Range	Load Current	
1	380 V	360~400V	0.5 A TYP.	

2. Lamp Power specifications

Specification	Description
Applicable Lamp	X1140A/X1240/X1140/P1340W/X1340WH : Osram Normal 190W, ECO 160W AC operation H6510BD : Osram Normal 210W, ECO 160W AC operation
Starting pulse from Ignitor	3.5KV

3. Power Protection

Item	Criteria
Short protection	No damage
OVP	16Vdc Max@12V 5Vdc Max@3.3V
OPP	DC-DC 130~250% PFC 130~160%

4. Surge test: Meet EN61000-4-5L $\leftrightarrow$ N 1KV, L, N $\leftrightarrow$ PE 2KV, Criteria B**5. Electrical Fast Transients (EFT):Meet EN61000-4-4**

1 KV, Criteria B

6. Voltage Dips: Meet EN61000-4-11

>95% reduction for 0.5 periods, Criteria B

7. Harmonic current test: Meet EN61000-3-2**8. Power BD Key Component List**


Constructional data form for electrical appliances	
Object/part No.	Technical data
Bridge Diode (BD601)	600V, 4A minimum
Storage capacitor (C619)	150 μ F , 450V 105°C minimum
Transistor (Q621)	600V,17A minimum

9. Ballast Data


Symbol	Parameter	Conditions	Min.	Typ.	Max.	Unit
Osram lamp	Output lamp power		184	X1140A/X1240/ X1140/P1340W/X1340WH: 190 H6510BD : 210	196	W
Vpi	Input Voltage	DC operating	320	380	400	V
	Input voltage for max 0.5 sec	In stand-by mode an overshoot of max. 420V and max. 500ms			420	V

System Block Diagram


For X1140A/X1240/X1140:



For P1340W/X1340WH:




For H6510BD:



Product Overview


Projector Outlook

Front/upper side




#	Description	#	Description
1	Control panel	5	Zoom ring
2	Projection lens	6	Focus ring
3	Tilt adjusting wheel	7	Remote control receiver
4	Power key and Power indicator LED		

Rear side




(X1140A/X1240/X1340W)




#	Description	#	Description
1	Mini USB connector	7	HDMI connector
2	Monitor loop-through output connector	8	Power socket
3	Analog RGB signal/HDTV/component video input connector	9	Tilt adjusting wheel
4	RS232 connector	10	Kensington™ lock port
5	S-Video input connector Composite video input connector	11	Component video input connector
6	Audio input connector Audio output connector		

Control Panel




#	Function	Description
1	LAMP	Lamp Indicator LED.
2	POWER indicator LED	Refer to the "Turning the Projector On/Off" section.
3	Keystone	Adjusts image distortion caused by tilting projection (± 40 degrees).
4	RESYNC	Automatically synchronizes the projector to the input source.
5	MENU	Launches the Onscreen Display (OSD) menu, returns to the previous step for the OSD menu operation or exits the OSD menu.
6	Power key	Refer to the "Turning the Projector On/Off" section.
7	TEMP	Temp Indicator LED.
8	SOURCE	Chooses RGB, component video, S-Video, composite video, HDMI or HDTV source.
9	Four directional selection keys	Selects items or makes adjustments to your selection
10	Empowering key	Enables unique Acer functions: eView, eTimer, ePower Management, e3D.

Remote Control Layout





X111/X1140/X1140A/X1240/
X1340W/P1340W



H6510BD

#	Function	Description
1	POWER	Refer to the "Turning the Projector On/Off" section.
2	ASPECT RATIO	To choose the desired aspect ratio.
3	ZOOM	Zooms the projector display in or out.
4	RESYNC	Automatically synchronizes the projector to the input source.
5	 Keystone	Adjusts image distortion caused by tilting projection (± 40 degrees).
	 Four directional selection keys	Selects items or makes adjustments to your selection.
6	Keypad 0~9	Press "0~9" to input a password in the "Setting" > "Security" OSD.
7	VGA	To change source to VGA. This connection supports analog RGB, YPbPr (480p/576p/720p/1080i/1080p), and YCbCr (480i/576i).
8	COMPONENT	To change source to component video. (YPbPr 480p/576p/720p/1080i/1080p and YCbCr 480i/576i)
9	S-VIDEO	To change source to S-Video.
10	HDMI™; HDMI™/DVI	To change source to HDMI™ (or DVI). (P1340W/ H6510BD only)
11	Infrared transmitter	Sends signals to the projector.

#	Function	Description
10	HDMI™; HDMI™/DVI	To change source to HDMI™ (or DVI). (P1340W/ H6510BD only)
11	Infrared transmitter	Sends signals to the projector.
12	Empowering key	Enables unique Acer functions: eView, eTimer, ePower Management, e3D.
13	FREEZE	To pause the screen image.
14	HIDE	Press "HIDE" to hide screen image; press again to display the image.
15	SOURCE	- Chooses RGB, component video, S-Video, composite video, HDMI or HDTV source. (X111/ X1140/X1140A/X1240/X1340W/P1340W) - Press to open the Source menu that allows you to select an input signal source. (H6510BD) 
16	MENU	Launches the Onscreen Display (OSD) menu, returns to the previous step for the OSD menu operation or exits the OSD menu.
17	PgUp/PgDn	For computer mode only. Use this button to select the next or previous page. This function is only available when connected to a computer via a USB cable.
18	VIDEO	To change source to composite video.
19	MUTE	To turn on/off the volume.
20	WIRELESS; LAN/WiFi	(No function)
21	◀◀ Rewind ▶▶ Play/Pause ■ Stop ▶▶▶ Fast-forward	(No function)
22	SD/USB A	(No function)
23	USB B	(No function)
24	3D	Press to open the 3D menu for adjusting 3D settings. 

(X111/X1140/X1140A/X1240)



(X1340W/P1340W)



(H6510BD)



Chapter 2 System Utilities


Firmware Upgrade SOP

Basic Operating

● Low-Power Standby Mode :

This mode is applied for normal situation. If you want to enter this mode, you could just plug in power cord. Power LED, Lamp LED, Temp LED will show Red for 1 sec, then Power LED will show Red.

When the Power LED, Lamp LED, Temp LED show Red, it means system is not ready for low-power standby. In another word, if only power LED shows Red, it means system is in low-power standby mode and the whole system is not supported by power except MCU and its related circuits. Meanwhile, the power consumption should under 0.5W.




● Download Mode :

This mode is applied for Download firmware, you can use USB or RS232 cable in the download mode.

One method to enter this mode is that you should press and hold keypad **Power and Menu** together, then plug in power cord. **Release the two keypads until the Power, Lamp and Temp LED show Red continuously.**

➤ **System will enter baud rate 115200 mode**

The default baud rate is 9600. This mode can change baud rate to 115200.



● Full-Power Standby Mode :

You should press and hold keypad **Power and Source** together, then plug in power cord. **Release the two keypads until the Power LED show Red continuously.**

The other method is to type RS-232 Command : `<CR>*Stby=H#<CR>`


In full-power standby mode, system will be supported by full power but not turn on projector. You can use DLP composer and communicate with DLP ASIC. Thus, you should download firmware in this mode.

➤ **System will enter EDID Write mode**

Plug in D-sub cable to write D-sub EDID by EDID read/write tool. X1140A and X1240 only need to write one of the two D-sub ports.

➤ **System will enter baud rate 115200 mode**

The default baud rate is 9600. This mode can change baud rate to 115200.



- **Download MCU Code : (in Low-Power Standby)**

For X1140A/X1240/X1140/H6510BD, MCU is WT69P3;
For P1340W/X1340WH, MCU is 51F516

Condition :

Situation 1 : MCU code is empty (The 1st time to plug in power cord)

Situation 2 : MCU version update

System Action :

System needs a few sec to download MCU itself.



Downloading : POWER and Temp LED will show red.

Download Success : System will go back Low-Power standby mode and Power LED will show red.



Download Fail: POWER and Lamp LED will show red.

Notice :

Do NOT interrupt power when downloading.

DLP Composer Lite Installation Process


(1) Installation

For X1140A/X1240/X1140, use DLP Composer Lite 9.0 or above version.


For P1340W/X1340WH/H6510BD, use DLP Composer Lite 11.0 or above version.

No matter which DLP composer Lite version is, the installation steps are the same.


1. Double click the Setup file for DLP Composer Lite 9.0 or above version.
2. When the Installation Wizard appears, click "Next".




3. Select to accept the License Agreement, than click "Next"



4. Click "Next" in the following steps to continue installation process.







Note:


The default installation directory is:

C:\Program Files\DLP Composer Lite9.2

If you want to install to a different directory (perhaps alongside a prior release of DLP Composer™ Lite), click the "Browse" button on the "Select Features" page.



- When finishing installation, click "Finish", and then restart your computer to complete the installation process.





(2) Setting for your first use

● Select Library: (For X1140A/X1240/X1140)

1. Unzip “DDP243x_Download_Tool_Ver1.4.rar” or later version to get the library.




2. When start to use this program to download at first time, you need to check if the library folder is existed under the path of Library (Click “Edit” →”Preferences”→ “Library”).




3. If the library files are not in the assigned path, save it into the path.

● Select Library: (For P1340W/X1340WH/H6510BD)

1. Unzip “DDP442X Download_Tool_Ver1.0.rar” or later version to get the file :
“FlashDeviceParameters.txt”.




2. Save the “FlashDeviceParameters.txt” into the DLP Composer Lite11.0 installed folder.




- **Set communication (for download by RS232):**


1. Select "Edit"->"Preference".




2. Select "Communications"-> "Serial Port" -> "Config".



3. Make sure the settings are the same as below figure-> Click "OK".



4. Click "OK".



(1) Download Procedure

● How to download

Download Tools Required :


Software required :

1. DLP Composer Lite
For X1140A/X1240/X1140, use DLP Composer Lite 9.0 or above version.
For P1340W/X1340WH/H6510BD, use DLP Composer Lite 11.0 or above version.
2. New version image file (*.img)

Hardware required :

1. PC or Notebook : With RS-232 or USB Connection
2. USB Download cable: Mini USB download cable
(optional: by RS232 Download cable : D-SUB 9pin female for both terminals.)

RS-232 Pin Assignment :



Pin	Definition	Pin	Definition
1	NC	2	RX
3	TX	4	NC
5	GND	6	NC
7	RTSZ	8	CTSZ
9	NC		


Firmware Download Procedure :

1. Connect RS-232 cable to PC and projector
2. Let projector be in **download mode**

LED : All LED will show red.



3. Launch “DLP Composer Lite v*. ” program




4. Check communication is “USB” or “Serial Port” (Depends on your download interface)


Choose "Preferences" from the "Edit" menu, click the "Communications" page and choose “USB” or “Serial Port”. And you can now use DLP Composer™ Lite to communicate with a projector via RS-232 using the Flash Loader tool.

USB Mode:


- For X1140A/X1240/X1140:




- For P1340W/X1340WH/H6510BD: (Product should be **0x4421**. If fill-in **0x2000**, you have to install USB driver before downloading. Install the driver from Star Menu->DLP Composer Lite11->Install DLP Device Drivers->Microsoft WinUSB)



RS-232 Mode:




RS-232 Configure Setting:




5. Select Flash Loader

- Browse Flash Image File
- Select Complete Image Download
- Skip boot Loader Area : **32KB**




6. Reset Bus to ready download

- Press “Reset Bus” and check the status which should show “Bus Reset”.
- Press “Start Download” to start.
- Press “Yes” to continue.




7. Download Complete

Check Status which should show "Download Complete."



Method to Enter Factory Menu

1. Press keypad **Power** and image will show Power Down OSD function
2. Press keypad **Left** twice then press **Menu**, then enter the Factory mode.



EDID Upgrade SOP

Equipment List

1. PC : with parallel (printer) port
2. EDID Board
3. Printer cable : 25pin male-female (connect PC to EDID board)
4. D-sub cable* : with full 15pin (connect EDID board to Projector)
5. HDMI cable*(connect EDID board to Projector)
6. DVI cable* (connect EDID board to Projector)

(*Note: Not every model's EDID input (D-sub, DVI, HDMI) is the same. Need to check what kind of file you need before download).

Setup Equipment


1. Let projector be in **Full-power standby mode** (Press "**Power**" and "**Source**" and plug in power cord into Projector immediately.)
2. Connect between PC, EDID board and the Projector:



PC with parallel (printer) port



"25pin male-female cable" (normal printer cable)



EDID board

Link to Projector: For DVI-D DDC download
(no need for X1140A, X1240, X1140, P1340W, X1340WH H6510BD)

Link to Projector: For HDMI DDC download
(no need for X1140A, X1240, X1140)

Please ignore this connector

Link to Main board: For D-sub DDC download



2. Need to set Jumper before using EDID board:

<Jumper setting >

J6 : 1,2 short

J8 : 1,2 short

J10 : short



3. How to use Download Tool:

Software Installation, Un-installation:

- Unzip the “Q-EDID” program files in the same directory.
- Install Q-EDID tool: Execute “Install Q-EDID.BAT” to install & register EDID Board into the computer.



- Un-install Q-EDID tool: If you want to uninstall this tool, execute “Uninstall Q-EDID.BAT”, then it will remove EDID Board from the computer.




How to use Download Tool:

(1) Execute EDID Tools V0.16:

1. Run “Q-EDID-V016.exe”.




2. Program will appear as below picture.



(2) Write EDID:

- **When write D-SUB/DVI EDID:**


1. EDID Type Selection: Choose "EDID 128 Bytes".
2. Open Files : Click "Open File" to select file "*.DDC"
(Note: If your DDC file name is not like "*.DDC" (e.g. "*.2dc"), please rename it to "*.DDC")
3. Write EDID: Click "Write EDID", and it will execute writing process.
4. While complete, it will show message as "Write EDID OK...".
(Note: Check cable connection before write. It will show Write EDID OK even the connection is not stable.)



(3) Read EDID:

- **Read D-SUB/DVI EDID:**

1. EDID Type Selection : Choose “EDID 128 Bytes”
2. Read EDID : Click “Read EDID”.
3. While complete, it will show message” Read EDID OK... ”, and the read-out DDC will show in the table in program.



Important Note:

- Be reminded to connect Only One port every time, because the software will not be able to identify the command signal from which port.
- After connecting all equipment, always read DDC before writing DDC to ensure the connection status is OK for writing DDC.

Serial Number Upgrade SOP

Hardware required

1. Standard RS232 Download cable
2. Personal computer or laptop computer

Software required


1. Acer_Service_Tool(Data)_3.1.exe

When need to use this Serial Number Upgrade program:

When it's time to replace Main board for repair or download new FW if it will cause factory data reset, it's necessary to rewrite original S/N and some adjustment values into Main board by the following process.


Upgrade procedure

1. Prepare the download equipment: RS232 cable connect to PC and projector
2. Plug power cord into projector, and the projector will be in stand by mode. Let the projector in full standby mode.
3. Execute "Acer_Service_Tool(Data)_3.1.exe", and it will appear as below picture.
4. Change to connected COM port and Click "Port Open" icon.




5. Read data from original Main board:

Click "Read system Data", and it will read the Adjustment data (except Auto keystone data) & Serial Number from projector and show the "Read complete" message in information block.



6. Click "Save" to save data into the assigned file name. Turn off projector.




7. Change new Main board:

- (1) Unplug power cable and RS232 cable from projector, and change new Main board into Projector.
- (2) After changing Main board, reconnect power cable and RS232 cable into Projector.

8. "Load from data" & "Retrieve System" :

(1) Click "Load from data" and select load file.

(2) Click "Retrieve System" to write the values into main board.














Chapter 3 System Disassembling and Replacement






Main Unit Disassembling

Tool: Screw Driver --Hex (#4-40) and Cross (Mechanical: M3, M4, Opt.Engine:M2, M2.5)











Process:



X1140A X1240 X1140 P1340W X1340WH H6510BD Dismantle SOP			
Step	Description		Tool
1	Disassemble the front case screw*1(M2.5*L10) and take off the lamp door. Disassemble the lamp module screw*1(M3*L6) and take off the lamp module, as the right Figure. For X1140A/X1240/X1140 : Disassemble the upper case screw*1(M3*L6). For P1340W/X1340WH/H6510BD : Disassemble the upper case screw*2(M3*L6).	   	screw driver
2	Disassemble the front case screw*2(M3*L6) and take off the front case. Disassemble the lower case screw*5(M3*L6). Take off the upper case(hook x7)	 	screw driver
3	Dismantle screw*1(M3*L6) on rear case, For X1140A/X1240: Dismantle screw*8(Hex#4-40) on rear case, then take off rear case. For X1140: Dismantle screw*4(Hex#4-40) on rear case, then take off rear case. For P1340W/X1340WH: Dismantle screw*8(Hex#4-40) and screw*1(M3*L6) on rear case, then take off rear case. For H6510BD: Dismantle screw*6(Hex#4-40), screw*2(M3*L6), and screw*1(M3*L8) on rear case, then take off rear case.	    	screw driver*2

4.1	For X1140A/X1240/X1140 : Extract the IR Wire and the speaker wire from mainboard, and take off the front case module. Dismantle C/W FPC wire, C/W sensor wire, blower fan wire, ballast 5pin wire, and outlet fan wire on main board. Disassemble the screw*5(M3*L6), and take off the shield main board.		screw driver
4.2	For P1340W/X1340WH : Extract the IR Wire from main board, and take off the front case module. Dismantle C/W FPC wire, C/W sensor wire, blower fan wire, ballast 5pin wire, outlet fan wire and speaker wire on main board. Disassemble the screw*5(M3*L6), and take off the shield main board.		screw driver
4.3	For H6510BD : Extract the IR Wire from main board, and take off the front case module. Dismantle C/W FPC wire, C/W sensor wire, blower fan wire, ballast 5pin wire, outlet fan wire and speaker wire on main board. Disassemble the screw*5(M3*L6), and take off the shield main board.		screw driver
5	Disassemble the main board and take off the outlet fan. Disassemble the screw*3(M3*L6) and take off the BKT main board	 Note: Circuit boards > 10cm² has been highlighted with the yellow rectangle as above image shows. Please detach the Circuit boards and follow local regulations for disposal.	screw driver

	For X1140A/X1240/X1140/P1340W/X1340WH: Extract the door switch wire, thermal wire, ballast 5pin wire, and lamp wire.	 Note: Circuit boards > 10cm² has been highlighted with the yellow rectangle as above image shows. Please detach the Circuit boards and follow local regulations for disposal.	screw driver
6.1	Disassemble the screw*2(M3*L6) of ballast. Take off the Power board and the ballast. Take off the gasket*1. Disassemble the screw*3(M3*L6) and take off the Engine module.	P1340W/X1340WH  Note: Circuit boards > 10cm² has been highlighted with the yellow rectangle as above image shows. Please detach the Circuit boards and follow local regulations for disposal.	screw driver
6.2	For H6510BD: Extract the door switch wire, thermal wire, ballast 5pin wire, and lamp wire. Disassemble the screw*2(M3*L6) of ballast. Take off the Power board and the ballast. Take off the gasket*2. Disassemble the screw*3(M3*L6) and take off the Engine module.	H6510BD  Note: Circuit boards > 10cm² has been highlighted with the yellow rectangle as above image shows. Please detach the Circuit boards and follow local regulations for disposal.	screw driver
7	Disassemble the screw*1(M3*L6), and take off the lamp box. Disassemble the screw*1(M3*L6), and take off the blower fan and blower nozzle.		screw driver
8	Extract the rubber foot rear *3, foot adjust rear, and foot adjust in the lower case		screw driver

X1140A X1240 X1140 P1340W X1340WH H6510BD Dismantle SOP

Step	Description		Tool
1	Take off the gasket*1. Disassemble the Ring Focus.		
2	Take off the LENS screw*3(M3*L4) and Ring Zoom screw*2(M2*L3). Take off the Ring Zoom	 	screw driver
3	Disassemble the spring screw*4(M3*L13.85), and take off the Hest-sink and DMD chip with Chip BD.	 	screw driver
4	Disassemble the Baffle DMD and Sponge DMD. Disassemble the screw*3 (M3*L4, M3*L5) and take off the CW module.	  	screw driver
5	Rotate to open the switch on socket, and take off the DMD chip board.	   Note: Circuit boards > 10cm² has been highlighted with the yellow rectangle as above image shows. Please detach the Circuit boards and follow local regulations for disposal.	
6.1	For X1140A/X1240/X1140/P1340W/X1340WH : Disassemble ILL module screw*2(M2*L4). Take off Clip CM Up, CM, Clip CM Front, Clip CM Side, screw*1(M2*L3.5) and sponge.	  	screw driver

6.2	For H6510BD: Disassemble ILL module(screw*3). Take off Clip CM, then take off the Concave mirror. Take off the sponge.		screw driver
7	Take off the Clip FM and Mirror Fold. Disassemble the screw*2(M2*L3). Take off the Clip LP and Baffle LP. Take off the LP module . Disassemble the LP screw*2(M2*L8).		screw driver

Module Assembly Key Point - Optical Engine

1. Light Pipe Module assembly and overfull alignment

- **For X1140A/X1240/X1140:**

1.1 Assembly LP Module to HSG DMD

- (1) Assembly "Clip LP" and lock with screw well (Fig. 1-1).
- (2) Press CLIP of RE_BKT_LP first, and then push it into the hole (Fig. 1-2).
- (3) Place LP Module on LP datum of "DMD HSG" and adjustment screw well (Fig. 1-3).
- (4) Assemble "Baffle LP" first (Fig. 1-4) & push "Baffle LP" to hook DMD HSG (Fig. 1-5).
- (5) When lock the screw of Baffle LP, the hand must push the left corner of Baffle LP before (Fig. 1-6).
- (6) Lock the screw of Baffle LP well then release the hand (Fig. 1-7),
- (7) Assemble two Overfill adjustment screws (M2, 8L) to HSG DMD (Fig. 1-8).

** Adjustment criteria refer to below item 1.2

1.2 Overfill Adjustment of LP Module

Overfill Adjustment Criteria:

- (1) Pre-assemble 2 adjusting screws.
- (2) Alignment Sequence:

Adjust "Horizontal Adjustment Screw" first, and then "Vertical Adjustment Screw".




Fig. 1-1




Fig. 1-2




Fig. 1-3




Fig. 1-4




Fig. 1-5




Fig. 1-6




Fig. 1-7




Fig. 1-8

● **For P1340W/X1340WH:**

1.3 Assemble LP Module to HSG DMD

- (1) Assemble two Overfill adjustment screws (M2) to HSG DMD (Fig. 1-9).
** Adjustment criteria refer to below item 1.4 & Fig. 1-10.
- (2) Hook Clip LP to HSG DMD, and lock with screw well. (Fig. 1-11).
- (3) Press CLIP of BKT LP first and push it into the hole (Fig. 1-12).
- (4) Place LP Module on LP datum of “DMD HSG” and adjustment screw well (Fig. 1-13).
- (5) Assemble “Baffle LP”, Hook top of Baffle LP first (Fig. 1-14) & Hook bottom of Baffle LP to HSG DMD well (Fig. 1-15).

1.4 Overfill Adjustment LP Module

Overfill Adjustment Criteria:

- (1) Pre-assemble 2 adjusting screws. Criteria as Fig.1-12
- (2) Alignment Sequence:
 - a. To adjust “Horizontal Adjustment Screw” firstly, and then “Vertical Adjustment Screw”.

- b. Refer to Fig. 1-12
- (3) For Overfill Re-adjustment:
 - a. Those 2 Adjustment Screws must be released closely to the “Pre-assembly” positions first (Fig. 1-12).
 - b. Follow adjustment steps as Item 1.4-(2).




Fig. 1-9




Fig. 1-10




Fig. 1-11




Fig. 1-12




Fig. 1-13




Fig. 1-14




Fig. 1-15

● **For H6510BD:**

1.5 Assembly LP Module to HSG DMD

- (1) Assembly two Overfill adjustment screws (M2) to HSG DMD (Fig. 1-16).
** Adjustment criteria refer to below item 1.6 & Fig. 1-17.
- (2) Press CLIP of BKT LP first and push it into the hole (Fig. 1-18).
- (3) Hook Clip LP to HSG DMD, and lock with screw well. (Fig. 1-19).
- (4) Placed LP Module on LP datum of “DMD HSG” and adjustment screw well, shown (Fig. 1-20).
- (5) Assembly “Baffle LP”, Hook top of Baffle LP first (Fig. 1-21) & screws (M2) well (Fig. 1-22).

1.6 Overfill Adjustment @ LP Module

Overfill Adjustment Criteria:

- (1) Pre-assembly 2 adjusting screws. Criteria shown as Fig.1-16
- (2) Alignment Sequence:
 - a. To adjust “Horizontal Adjustment Screw” firstly, and then “Vertical Adjustment Screw”.
 - b. Refer to Fig. 1-16
- (3) For Overfill Re-adjustment:
 - a. Those 2 Adjustment Screws must be released closely to the “Pre-assembly” positions first (Fig. 1-19).
 - b. Follow adjustment steps shown in Item 1.6 (2).




Fig. 1-16




Fig. 1-17




Fig. 1-18




Fig. 1-19




Fig. 1-20




Fig. 1-21




Fig. 1-22

2. Assembly FM:

- **For X1140A/X1240/X1140:**

2.1 Place FM on “HSG DMD” surface(Fig. 2-1) and use “Clip FM” to fix FM(Fig. 2-2).




Fig. 2-1




Fig. 2-2

- **For P1340W/X1340WH:**

2.2 FM Module Assembly

- (1) Check mark point of FM and place FM on “Sub HSG” surface (Fig. 2-3, 2-4).
- (2) Assemble “Clip FM Z5” to fix FM(Fig. 2-5).
- (3) Check Clip FM hook Sub HSG Well (Fig. 2-6)




Fig. 2-3




Fig. 2-4




Fig. 2-5




Fig. 2-6

● **For H6510BD:**

2.3 FM Module Assembly

- (1) Check mark point of FM and place FM on “HSG DMD” surface (Fig. 2-7-1, 2-7-2).
- (2) Assemble “Clip FM ” to fix FM(Fig. 2-8).
- (3) Check Clip FM hook HSG DMD and Screw Well (Fig. 2-8)




Fig. 2-7-1




Fig. 2-7-2




Fig. 2-8

3. Assembly HSG ILL Module:

- **For X1140A/X1240/X1140:**

3.1 CM Assembly

- (1) Insert “Clip CM Side” first, and then place “Clip Front CM” to fixed-shaft of ILL SUB before locking screw (Fig. 3-1, Fig. 3-2).
- (2) Assemble Mylar SUB HSG to HSG ILL well (Fig. 3-3).
- (3) Assemble CM to HSG ILL and to make CM contact three datum on the HSG ILL well (Fig. 3-3).
- (4) Assemble “MYLAR CM” to the CMD firstly, “CLIP TOP CM”(with forceps) to the “HSG ILL” (Fig. 3-4,).
- (5) Check and make sure “CLIP of CM” hooks the HSG ILL very well (Fig. 3-5).




Fig. 3-1




Fig. 3-2




Fig. 3-3




Fig. 3-4




Fig. 3-5

● **For P1340W/X1340WH:**

3.2 CM Assembly

- (1) Place "Clip CM Front" first, and screw well (Fig. 3-6).
- (2) Insert Clip CM Side to Sub HSG (Fig. 3-7).
- (3) Assemble CM to Sub HSG and make CM contact Sub HSG datum well (Fig. 3-8).
- (4) Assemble Clip CM Up to Sub HSG & Check the feature for Clip CM Up XGA. (Fig. 3-9,).
- (5) To check and make sure Clip CM Up to hook the Sub HSG Well (Fig. 3-10).
- (6) Paste "Sponge tube AL" on cannellure of" HSG ILL" (Fig. 3-10).




Fig. 3-6




Fig. 3-7




Fig. 3-8

Check Feature




Fig. 3-9




Fig. 3-10

● **For H6510BD:**

3.3 CM Assembly

- (1) Assemble CM to Sub HSG and to make CM contact Sub HSG datum Well (Fig. 3-11, 3-12).
- (2) Hook Clip CM to Sub HSG first and push it into the hole. (Fig. 3-13, 3-14).
- (3) To check and make sure Clip CM hooks the Sub HSG Well (Fig. 3-15).
- (4) Paste "Mylar Cover Sub" to cover "Clip CM" and "Sub HSG" (Fig. 3-15).
- (5) Paste "Sponge tube AL" on cannellure of "Sub HSG" (Fig. 3-15).




Fig. 3-11




Fig. 3-12




Fig. 3-13




Fig. 3-14




Fig. 3-15




Fig. 3-16




Fig. 3-17

4. AL, HSG ILL and HSG DMD Assembly:

- **For X1140A/X1240/X1140/P1340W/X1340WH:**

4.1 Placed “AL” on the “HSG DMD”. The “raised surface” of “AL” shall toward “DMD direction” (Fig. 4-1).

4.2 To assemble “HSG ILL SUB Module” with “HSG DMD” and cover over on “AL” and the then lock with screws(Fig. 4-2).




Fig. 4-1




Fig. 4-2

● **For H6510BD:**

4.3 Placed “AL” on the “HSG DMD”. The “raised surface” of “AL” shall toward “DMD direction” (Fig. 4-3).

4.4 To assemble ” SUB HSG Module” with “HSG DMD” and cover over on “AL” and the then lock with screws(Fig. 4-4).




Fig. 4-3




Fig. 4-4

4.5 Paste “Sponge Anti Dust” on Clearance between “Sub HSG” and “HSG DMD” (Fig. 4-5-1~2).




Fig. 4-5-1




Fig. 4-5-2

5. DMD and Chip B/D Module:

5.1. Judge Chip B/D and DMD alignment keying first (Fig. 5-1, 5-2).

5.2. Align keying and Assemble DMD to Chip B/D (Fig. 5-3).

5.3. Push DMD slightly and use screwdriver rotate clockwise button to lock (close notation) DMD on Chip B/D (Fig. 5-4).




Fig. 5-1

Alignment keying




Fig. 5-2




Fig. 5-3




Fig. 5-4

6. Assembly Optical Engine:

6.1 Assemble "BKT Link Lamp & CW shield" on "DMD HSG" and then lock with screws well (Fig. 6-1).




Fig. 6-1

7. Assembly OP ENG

7.1 Assemble "Baffle DMD" to "HSG DMD" (Fig.7-1-1, 7-1-2).

7.2 Assemble "Sponge DMD" to "HSG DMD" (Fig. 7-1-1, 7-1-2)

7.3 Assemble Chip B/D Module to "HSG DMD" (Fig. 7-2).

● For X1140A/X1240/X1140:




Fig.7-1-1

● For P1340W/X1340WH:




Fig. 7-1-2

Fixed shafts of
DMD HSG




Fig.7-2-1





Fig.7-2

● **For H6510BD:**

- (1) Assemble "Baffle DMD" to "HSG DMD" (Fig.7-3).
- (2) Assemble Chip B/D Module to "HSG DMD" (Fig. 7-4, Fig. 7-5).

Alignment keying



Baffle DMD

Fig. 7-3

Fixed shafts of
DMD HSG




Fig.7-4




Fig.7-5

7.4 Assemble Thermal Pad & Gasket Heat-sink then place contact DMD (Fig. 7-6-1).

- (1) Press center of Heatsink before assemble spring screw*4, then keeps press until spring screw assembly finish.
- (2) Pre-fastening Sequence: [1] - [2] - [3] - [4].
- (3) Fastening Sequence: [2] - [1] - [4] - [3].
- (4) Screw Torque must be confirmed to be 6 kg-cm.




Fig. 7-6-1

- For X1140A/X1240/X1140/P1340W/X1340WH:




Fig. 7-6-2

- For H6510BD:




Fig. 7-6-3

Assemble “CW Module” and “Cover HSG DMD” to “DMD HSG” then lock with screws well (Fig.7-6-4).




Fig. 7-6-4

7.5 Assemble “CW Module” to “DMD HSG” and lock with screws well (Fig.7-4).




Fig.7-4

7.6 Assemble “Sponge Antidust” well (Fig. 7-5-1~2).




Fig.7-5-1






Fig.7-5-2

7.7 Assemble “PL Lens” and lock with screws well (Fig. 7-6).


- (1) Assemble Lens and the Assembly direction must be horizontal, and do not impact CM.
- (2) Pre-fasten Screws firstly. Screw Torque must be confirmed to be 1-2 kg-cm. (Fig. 7-6)
- (3) Fasten the Screws well. Screw Torque must be confirmed to be 2.5-3.5 kg-cm. (for H6510BD, Torque is 4.0-5.0 kg-cm.)(Fig. 7-6)



7.8 Assemble “Ring Zoom” and lock with screws well (Fig. 7-7).





7.9 Assemble “Ring Focus” well (Fig. 7-8).




Module Assembly Key Point - Mechanical


1. Lower case module assembly




(For H6510BD) : Add a sponge on lower case




2. Assemble power board with ballast cable on lower case



Notice : Connect power board with ballast board at first




Notice : Assemble power board into these 2 hooks




Notice: Power board must be go through these 2 boss

3. Assemble lamp box assembly on lower case




Door switch wire

Lamp wire





Plug lamp wire first

Notice: lamp wire cable routing



4. Assemble nozzle assembly on lower case





Plug lamp wire

5. Assemble speaker & FAN with cable on lower case




FAN

Speaker & FAN wire must be under this hook


Speaker

6. Cable routing of thermal break wire & door switch wire

● For X1140A/X1240/X1140/P1340W/X1340WH:




● For H6510BD:




7. Assemble engine assy and EMI gasket on lower case
Add gaskets on OPT to contact main frame


● For X1140A/X1240/X1140:




● For P1340W:



● For X1140A/X1240/X1140/P1340W/X1340WH:




● For H6510BD : Screw*3




Screw*3


8. Assemble main bracket.




9. Assemble main board and main shielding Plug cable



● For X1140A/X1240/X1140:




● For P1340W/X1340WH:



IR CW cable CW FFC Blower Ballast Axial fan Speaker


● For H6510BD :





IR CW cable CW FFC Blower Ballast Axial fan Speaker

MB Shielding assembly:

● For X1140A/X1240/X1140:




● For P1340W/X1340WH/H6510BD :



Notice Pins
position, and plug
accurately

Cable routing for CW cable:

- For X1140A/X1240/X1140/P1340W/X1340WH :




10. Assemble rear case


- For X1140A/X1240:





- For X1140:



- For P1340W/X1340WH:



● For H6510BD:



Screw

11. Assemble front case pre-assy
a. Pre-Assemble IR BD into front cover




- b. Pre-Assemble screw into front cover



Screw


Plug IR cable



IR wire must be arranged into Rib clamp.


12. Assemble upper case

(1) Sub upper case--Assemble keypad :



Keypad

(2) Assemble film anti-explode on upper case



Film:
Align this edge




Screw



Press hook x3 to
fix upper case



13. Assemble front case

- For X1140A/X1240/X1140:



Plug IR board wire

● For P1340W/X1340WH/H6510BD:



14. Assemble lamp door






Assemble by this direction

Chapter 4 Troubleshooting

System Analysis



Optical Problems Checking Items


No.	Item	Trouble Shooting Guide
1	Brightness	1. Change lamp
2	Uniformity	1. Change lamp
3	FOFO Contrast	1. Check ADC calibration 2. Check user's menu brightness & contrast are default 3. Clean DMD 4. Clean PL 5. Check ILL stop assy
4	ANSI Contrast	1. Clean PL 2. Clean DMD 3. Change PL
5	Color	1. Check color wheel delay 2. Check CW 50% point. Replace CW if necessary
6	Color Uniformity	1. Change lamp
7	Blue Edge	1. Refer to next "Blue Edge" Trouble Shooting section 2. Change CM 3. Change SUB HSG
8	Blue/Purple Border	1. Refer to next page 2. Change CM 3. Change SUB HSG
9	Focus	1. Change Projection Lens 2. Check PL datum and DMD parallel
10	Dust	Clean DMD
11	Horizontal/Vertical Strips	1. Check connector between chip BD and Main BD 2. Re-install DMD with chip BD 3. Check if any pin of C-Spring is missing, damaged or dirty 4. Change new Chip BD/C-Spring 5. Change new DMD
12	Pixel Fail	Change new DMD (Refer to next "DMD Image Quality" section)

- **“Blue Edge” Trouble Shooting:**

1. Re-adjust “Overfill” first.

For Overfill Re-adjustment:

- i. Those 2 Adjustment Screws must be released for around 2 mm first.
- ii. Alignment Sequence:
 - a. To adjust “Horizontal Adjustment Screw” firstly, then “Vertical Adjustment Screw”.
 - b. Refer to below Figure.



2. Re-assemble LP module—include LP, LP Baffle, LP clip.

● DMD Image Quality

1. SCOPE

This document specifies the image quality requirements applicable to the DLP®.55SVGA Type X and Series 450 Value Component Set, and DLP™.65WXGA-800 Value Component Set. The Component Set provides the digital imaging functionality based on Digital Micromirror Device (DMD) technology.

2. Definitions

Blemish

A blemish is an obstruction, reflection, or refraction of light that is visible, but out of focus in the projected image under specified conditions of inspection(see Table 1). It is caused by a particle, scratch, or other artifact located in the image illumination path.

Dark pixel

A single pixel or mirror that is stuck in the OFF position and is visibly darker than the surrounding pixels.

Bright pixel

A single pixel or mirror that is stuck in the ON position and is visibly brighter than the surrounding pixels.

Unstable pixel

A single pixel or mirror that does not operate in sequence with parameters loaded into memory. The unstable pixel appears to be flickering asynchronously with the image.

Adjacent pixel

Two or more stuck pixels sharing a common border or common point, also referred to as a cluster.

Reset Boundary Artifact

The reset boundary artifact is a single row of pixels on the reset group boundaries that are visibly darker or lighter than the neighboring rows of pixels.

Pond of mirrors (POM)

POM is a rectangular array of off-state mirrors surrounding the active area.

Eyecatcher

Eyecatcher's are blemishes appearing in the area outside of the Active Area. These are due to particles and various DMD window or window aperture "defects" including: digs, voids, and scratches.

Border Artifacts

Border artifacts are a general category of image artifacts that may show up on screen in the area outside of the active array. Border artifacts include: Exposed Bond Wires, Exposed Metal 2, and Reflective Edge.

Bond Wires

Bond Wires are the electrical connections between the die and the DMD ceramic package. If visible, they will appear as short light parallel lines outside of the Pond of Mirrors (POM).

Exposed Metal 2

Exposed Metal 2 is due to a shift in positioning of either the die or the window aperture, which may allow light to be reflected off of the layer of metal 2 that is below the super structure (mirrors). This defect is located outside of the POM.

Reflective Edge

Reflective Edge is light that may reflect from the edge of the DMD window aperture onto the projection screen. It will appear as a thin diffuse line outside of the POM.

Blue 60 Screen

The Blue 60 screen is used to test for major dark blemishes. All areas of the screen are colored a Microsoft Paintbrush blue 60 (green and red set at 0, blue set at 60).

NOTE: If linear degamma is not used then the Microsoft Paintbrush values must be adjusted to match the degamma table being used in order to generate an equivalent blue level on the test screen image.

Gray 10 Screen

The Gray 10 screen is used to test for major light blemishes. All areas of the screen are colored a Microsoft Paintbrush gray 10 (green, red, and blue set at 10).

NOTE: If linear degamma is not used then the Microsoft Paintbrush values must be adjusted to match the degamma table being used in order to generate an equivalent gray level on the test screen image.

Gray 30 Screen

The Gray 30 screen is used to test for the reset boundary artifact. All areas of the screen are colored a Microsoft Paintbrush gray 30 (green, red, and blue set at 30).

NOTE: If linear degamma is not used then the Microsoft Paintbrush values must be adjusted to match the degamma table being used in order to generate an equivalent gray level on the test screen image.

3. ACCEPTANCE REQUIREMENTS

Conditions of Acceptance

All DMD image quality defects must be determined under the following projected image test conditions:

- a. Test Set degamma shall be linear.
- b. Test Set brightness and contrast settings shall be set to nominal.
- c. The diagonal size of the projected image shall be a minimum of 60 inches.
- d. The projection screen shall be 1X gain.
- e. The projected image shall be inspected from an 8 feet minimum viewing distance.
- f. The image shall be in focus during all Table 1 tests.

Test Sequence

Tests shall be run in the sequence listed in Table 1~2.

TABLE 1. Image Quality Specification (for X1140A/X1240/X1140)

SEQ #	TEST	SCREEN	ACCEPTANCE CRITERIA
1	Major Dark Blemish	Blue 60	1. ≤ 4 visible dark blemishes are allowed in the active area 2. No blemish will be $> 1.5''$ long/diameter
2	Major Light Blemish	Gray 10	1. ≤ 4 visible light blemishes are allowed in the active area 2. No blemish will be $> 1.5''$ long/diameter
3	Reset Boundary Artifact	Gray 30	1. No reset boundary artifacts allowed
4	Eyecatchers Border Artifacts	Any screen	1. Eyecatcher and border artifacts are allowed
5	Projected Images	Any screen	1. No adjacent pixels 2. No bright pixels in Active Area 3. No unstable pixels in Active Area 4. ≤ 1 bright pixel in the POM 5. ≤ 4 dark pixels in the Active Area 6. No DMD window aperture shadowing on the Active Area 7. Minor blemishes are allowed

TABLE 2. Image Quality Specification (for P1340W/X1340WH)

SEQ #	TEST	SCREEN	ACCEPTANCE CRITERIA
1	Major Dark Blemish	Blue 60	1. ≤ 4 visible dark blemishes are allowed in the active area 2. No blemish will be $> 1''$ long/diameter
2	Major Light Blemish	Gray 10	1. ≤ 4 visible light blemishes are allowed in the active area 2. No blemish will be $> 1''$ long/diameter
3	Reset Boundary Artifact	Gray 30	1. No reset boundary artifacts allowed
4	Eyecatchers Border Artifacts	Any screen	1. Eyecatcher and border artifacts are allowed
5	Projected Images	1. Any screen 2. Gray 10 3. Any screen 4. Gray 10 5. Whit 6. Any screen 7. Any screen	1. No adjacent pixels 2. No bright pixels in Active Area 3. No unstable pixels in Active Area 4. ≤ 1 bright pixel in the POM 5. ≤ 7 dark pixels in the Active Area 6. No DMD window aperture shadowing on the Active Area 7. Minor blemishes are allowed

TABLE 3. Image Quality Specification (for H6510BD)

SEQ#	Test	SCREEN	ACCEPTANCE CRITERIA
1	Major Dark Blemish	Two Zone Blue 60	1. ≤ 4 visible dark blemishes are allowed in the active area 2. No blemish will be $> 1.5''$ long/diameter
2	Major Light Blemish	Two Zone Gray 10	1. ≤ 4 visible dark blemishes are allowed in the active area 2. No blemish will be $> 1.5''$ long/diameter
3	Non-Active Area Artifacts / Border Defects	Any Screen	1. Non-Active Area Artifacts are acceptable 2. Border Defects are acceptable
4	Reset Boundary Artifact	Any Screen	Reset boundary artifacts are acceptable
5	Minor Blemishes	Any screen	1. ≤ 8 total minor blemishes allowed 2. No blemished shall be > 5 inches long/diameter
6	Projected Images	1. Any screen 2. Gray 10 3. Any screen 4. Gray 10 5. White	1. No adjacent pixels 2. No bright pixels in Active Area 3. No unstable Pixels in Active Area 4. ≤ 1 right pixel in the POM 5. 0 dark pixels in Zone A and ≤ 2 in Zone B

Notes:

1. Projected blemish numbers include the count for the shadow of the window artifact in addition to the artifact itself.
2. During all Table 1 tests, projected images shall be inspected in accordance with the conditions of inspection specified in Section 3.
3. The rejection basis for all cosmetic DMD defects (scratches, nicks, particles) will be the projected image tests referenced in Table 1.
4. Devices that meet this image quality specification but are deemed undesirable by the customer may not be returned to TI without prior approval by TI.
5. Screens $< \text{Gray}10$ shall not be used as a basis for rejecting a DMD for image quality.


Power Supply Problems Checking Flow

1. Introduction


This document is prepared to be a guide to repair trouble sets, some problems happen more frequently are taken as example in it.


2. Problems

(a) No power



(b)Lamp cannot be turned on





LED Messages Definition

External Status indicator

LED Name	Detailed Description
Power LED	Display the power on/off sequence status
Lamp Status LED	Display the Lamp status (Lamp fail, Lamp spoil etc.)
Temperature Status LED	Display the Thermal status (Fan Fail, Over Temperature, etc.)


	Power_LED	Power_LED	Lamp_LED	Temp_LED
	BLUE	RED	RED	RED
Power Plug	-	Flash ON to OFF	Flash ON to OFF	Flash ON to OFF
Standby	--	ON	--	--
Power button ON	ON	--	--	--
Lamp retry	0.5 second H(On), 0.5 second L(Off) flashing	--	--	--
Cooling state	--	0.5 second H(ON), 0.5 second L(OFF) flashing	--	--
Power button OFF: Cooling completed; Standby Mode	--	ON	--	--
Firmware Download	--	ON	ON	ON--
Thermal sensor error. OSD shows "Projector Overheated"	ON	--	--	ON
Fan lock error OSD shows red "Fan Fail, Will automatically turn off soon"	ON	--	--	0.5 second H(On), 0.5 second L(Off) flashing
Lamp error (Lamp, ballast)	ON	--	ON	--
Color Wheel fail	ON	--	0.5 second H(ON), 0.5 second L(OFF) flashing	--

Error Count Messages Definition

● For X1140A/X1240/X1140:

Error Count	Definition	Specification
LAMP Fail error	LAMP OFF	DETECT LAMPLIT
FAN 1 Speed Error	LAMP FAN SPEED ERROR	SPEED OVER $\pm 20\%$
FAN 2 Speed Error	BLOWER FAN SPEED ERROR	SPEED OVER $\pm 20\%$
Sensor 1 Open Error	Main Board SENSOR ERROR	DETECT Sensor 1
Sensor 1 Short Error	Main Board SENSOR ERROR	DETECT Sensor 1
Temperature 1 Error	over limited temperature	DETECT Sensor 1
FANIC 1 I2C ERROR	I2C communication error	DETECT Fan IC


Note: Fan and Sensor placement refers below figure:



● For P1340W/X1340WH/H6510BD:

Error Count	Definition	Specification
LAMP Fail error	LAMP OFF	DETECT LAMPLIT
FAN 1 Speed Error	BLOWER FAN SPEED ERROR	SPEED OVER $\pm 20\%$
FAN 2 Speed Error	LAMP FAN SPEED ERROR	SPEED OVER $\pm 20\%$
Sensor 1 Open Error	Main Board SENSOR ERROR	DETECT Sensor 1
Sensor 1 Short Error	Main Board SENSOR ERROR	DETECT Sensor 1
Temperature 1 Error	over limited temperature	DETECT Sensor 1
FANIC 1 I2C ERROR	I2C communication error	DETECT Fan IC


Note: Fan and Sensor placement refers below figure:



RS232 Connection

1. Connection:

The illustration of connection between PC and Projector is shown below.




<CAUTION>

- ◆ Make sure that your computer and projector are turned off before connection.
- ◆ Power on the computer first, and then plug the power cord of the projector. (It may cause Com port incorrect function, if you do not follow this instruction)
- ◆ Adapters may be necessary depending on the PC connected to this projector. Please contact with your dealer for further details.

2. Hardware connection


<Download cable 1>

Standard RS232 Download cable (SPEC as below), D-sub 9-pin Female for Both terminals



1	BLACK	1
2	BROWN	3
3	RED	2
4	ORANGE	4
5	YELLOW	5
6	GREEN	6
7	BLUE	8
8	PURPLE	7
9	GRAY	9
CASE	DRAIN WIRE	CASE

<Pin assignment for this two end>



Pin	Definition	Pin	Definition
1	NC	2	RX
3	TX	4	NC
5	GND	6	NC
7	RTSZ	8	CTSZ
9	NC		

Interface Settings

RS-232 protocol	
Baud Rate	9600 bps
Data Length	8 bit
Parity Check	None
Stop Bit	1 bit
Flow Control	None

Command Category

Refer to Appendix A

Adjustment / Alignment Procedure



Content:

1. Color Wheel Delay Alignment
2. Overfill adjustment
3. PC Alignment Procedure
4. Keystone Calibration

1. Color Wheel Delay Alignment

Procedure:




1. Enter Factory Mode
2. Enter Block 1
3. Change CW Delay by adjusting the following gray pattern to smooth



32 Gray pattern

2. Overfill adjustment (Blue Edge adjustment)

1. "Full White Pattern" is suggested for this alignment.
2. Adjust 2 LP-alignment Screws (upper side / lower front side of Optical Engine) behind Color Wheel.
3. Alignment Criteria is to adjust these 2 screws until "No Dark Edges" and "No Shadows" can be observed in image.




3. PC Alignment Procedure

Equipment :

- Pattern generator (Chroma-2327)

OSD Default value :

Item	Value
Cal R Offset	512
Cal G Offset	512
Cal B Offset	512
Cal R Gain	1024
Cal G Gain	1024
Cal B Gain	1024
YPbPr R Offset	512
YPbPr B Offset	512



Pattern 1

Procedure :

1. Connect power, D-sub, into projector.
2. Change Timing and pattern of pattern generator:
3. Timing: 1024*768 @60Hz (XGA)
1280*800 @60Hz (for H6510BD)
4. Pattern: As the figure below {A near white color (240,240,240) and a near black color(16,16,16)}
5. Light on projector
6. Set user OSD values to default.
7. Enter factory mode.
8. Set Factory values to default.
9. Press "Calibration RGB" to let the black level to just distinguish, and the light output of white level to just max.
10. Check the 32 levels of gray. All steps must appear.
11. Calibrate Dsub_1 only .(Dsub_2 follows Dsub_1)


4. Keystone Calibration (Only for X1140A/X1240/P1340W/X1340WH)

Condition : Horizontal plane(0°)

1. Make projector be horizontal
2. Enter factory menu
3. Enter into Block 3 in factory menu
4. Press "AutoKeystoneAngleCalEnable <Press L or R>" to enable this function.
5. Set the projector on the table adjust to 0 degree.
6. Select item "AutoKeystoneCal"
7. Press key Left or Right to do auto calibration
8. Finish 0° calibration and bellow items will show data:

$-5 \leq \text{AutoKeystoneXCal} \leq 43$


$\text{AutoKeystoneXOffset} \leq 20$



Chapter 5 FRU List


Exploded Diagram

Module 1 – Total Exploded View




NO.	PART NAME	Q'TY
1	CASE UPPER X1140A	1
2	CASE LOWER PC,X1140A	1
3	CASE FRONT PC,X1140A	1
4	CASE REAR X1140A	1
5	DOOR LAMP PC ,X1140A	1
6	ASSY KEY X1140A	1
7	LENS UPPER X1140A	1
8	LENS LED X1140A	1
9	LENS IR X1140A	1
10	DOOR LAMP PC ,X1140A	1
11	NOZZLE TOP PPS X1111A	1
12	NOZZLE BOTTOM PPS X1111A	1
13	FOOT ADJUST FRONT	1
14	FOOT ADJUST REAR PC S1210	1
15	RUBBER FOOT PAD	3
16	BKT MAIN BD SECC	1
17	SHIELD MAIN BD SPTE	1
18	FILM LAMP EXPLODE X1140A	1
19	FAN 70*70*25 170MM AD07012DB	1
20	FAN 50*50*20 140MM AB5012DX	1
21	SPK 2W 8OHM 210MM	1
22	Main BD	1
23	Power BD	1
24	BALLAST 230W P-VIP SATURN10-2	1
25	PCBA IR BD MI MP522	1
26	ASSY OPT ENG Z2 SVGA X1140A	1

Module 2 – ASSY UPPER CASE




Module 3 – ASSY LOWER CASE




Module 4 – ASSY REAR CASE


For X1140A/X1240:




For X1140:



For P1340W/X1340WH:












For H6510BD:



















FRU List




Model	CATEGORY	PARTNAME	ACER PART NO.	Photo
X1140A X1240	REMOTE CONTROLLER	Projector Remote Control	VZ.JCQ00.001	
P1340W/X1340WH	REMOTE CONTROLLER	Projector Remote Control	VZ.JDW00.001	
X1140A	BOARD	MAIN BOARD	55.JERJ3.001	
X1240	BOARD	MAIN BOARD	55.JF2J3.001	
X1140	BOARD	MAIN BOARD	55.JFWJ3.001	
P1340W/X1340WH	BOARD	MAIN BOARD	55.JF4J3.001	
X1140A	BOARD	POWER BD	55.JERJ3.002	
X1240 X1140 P1340W/X1340WH	BOARD	POWER BD	55.JFWJ3.002	
X1140A X1240 P1340W/X1340WH	BOARD	BALLAST BD	55.JERJ3.003	
X1140A X1240 P1340W/X1340WH	BOARD	DMD CHIP BOARD	55.JERJ3.004	
X1140A X1240 P1340W/X1340WH H6510BD	BOARD	IR SENSOR BOARD	55.J900Q.005	

H6510BD	CASE/COVER/BRACKET ASSEMBLY	REAR CASE	60.JFZJ3.001	
X1140A X1240	CASE/COVER/BRACKET ASSEMBLY	UPPER CASE	60.JERJ3.002	
P1340W/X1340WH	CASE/COVER/BRACKET ASSEMBLY	UPPER CASE	60.JF4J3.002	
H6510BD	CASE/COVER/BRACKET ASSEMBLY	UPPER CASE	60.JFZJ3.002	
X1140A X1240	CASE/COVER/BRACKET ASSEMBLY	LOWER CASE	60.JERJ3.003	
P1340W/X1340WH	CASE/COVER/BRACKET ASSEMBLY	LOWER CASE	60.JF4J3.003	
H6510BD	CASE/COVER/BRACKET ASSEMBLY	LOWER CASE	60.JFZJ3.003	
X1140A X1240	CASE/COVER/BRACKET ASSEMBLY	FRONT CASE	60.JERJ3.004	
P1340W/X1340WH	CASE/COVER/BRACKET ASSEMBLY	FRONT CASE	60.JF4J3.004	
H6510BD	CASE/COVER/BRACKET ASSEMBLY	FRONT CASE	60.JFZJ3.004	
X1140A X1240	CASE/COVER/BRACKET ASSEMBLY	DOOR LAMP ASSY	60.JERJ3.005	
P1340W/X1340WH H6510BD	CASE/COVER/BRACKET ASSEMBLY	DOOR LAMP ASSY	60.JF4J3.005	

X1140A	CASE/COVER/BRACKET ASSEMBLY	FOCUS RING	60.JERJ3.006	
X1240 P1340W/X1340WH	CASE/COVER/BRACKET ASSEMBLY	FOCUS RING	60.J900Q.009	
H6510BD	CASE/COVER/BRACKET ASSEMBLY	FOCUS RING	60.JFZJ3.005	
X1140A X1240 P1340W/X1340WH	CASE/COVER/BRACKET ASSEMBLY	ZOOM RING	42.JBJ0Q.001	
H6510BD	CASE/COVER/BRACKET ASSEMBLY	ZOOM RING	60.K130Q.005	
X1140A X1240	CASE/COVER/BRACKET ASSEMBLY	KEYPAD	60.JERJ3.007	
P1340W/X1340WH	CASE/COVER/BRACKET ASSEMBLY	KEYPAD	60.JF4J3.006	
H6510BD	CASE/COVER/BRACKET ASSEMBLY	KEYPAD	60.JFZJ3.006	
X1140A X1240	Lamp Module	Lamp Module for X1140A	MC.40111.001	
P1340W/X1340WH	Lamp Module	Lamp Module for P1340W	MC.40111.001	
H6510BD	Lamp Module	Lamp Module for H6510BD	MC.JFZ11.001	
X1140A X1240	OPTICAL DEVICE	COLOR WHEEL MODULE	57.JERJ3.001	

P1340W/X1340WH	OPTICAL DEVICE	COLOR WHEEL MODULE	57.JDP0Q.002	
H6510BD	OPTICAL DEVICE	COLOR WHEEL MODULE	57.JFZJ3.001	
X1140A X1240	OPTICAL DEVICE	LIGHT PIPE	57.JERJ3.002	
P1340W/X1340WH	OPTICAL DEVICE	COLOR WHEEL MODULE	57.JF4J3.001	
H6510BD	OPTICAL DEVICE	LIGHT PIPE	57.JFZJ3.002	
X1140A	OPTICAL DEVICE	LENS ZOOM	57.JERJ3.003	
X1240	OPTICAL DEVICE	LENS ZOOM	57.JCQ0Q.003	
P1340W/X1340WH	OPTICAL DEVICE	LENS ZOOM	57.JDP0Q.004	
H6510BD	OPTICAL DEVICE	LENS ZOOM	57.JFZJ3.003	
X1140A	OPTICAL DEVICE	DMD CHIP	57.JERJ3.004	
X1140A	OPTICAL DEVICE	DMD CHIP	57.JERJ3.005	
X1240	OPTICAL DEVICE	DMD CHIP	57.JDM0Q.004	

X1240	OPTICAL DEVICE	DMD CHIP	57.JDM0Q.005	
P1340W/X1340WH	OPTICAL DEVICE	DMD CHIP	57.JDPJ3.001	
H6510BD	OPTICAL DEVICE	DMD CHIP	57.JFZJ3.004	
X1140A	OPTICAL DEVICE	ENGINE	57.JERJ3.006	
X1240	OPTICAL DEVICE	ENGINE	57.JF2J3.001	
P1340W/X1340WH	OPTICAL DEVICE	ENGINE	57.JF4J3.002	
H6510BD	OPTICAL DEVICE	ENGINE	57.JFZJ3.005	
X1140A X1240 P1340W/X1340WH H6510BD	FAN	FAN 60*60*25 150MM	23.JERJ3.001	
X1140A X1240 P1340W/X1340WH H6510BD	FAN	FAN 80*80*25 170MM	23.JERJ3.002	
X1140A X1240	SPEAKER/MICROPHONE	SPEAKER	23.JERJ3.003	
P1340W/X1340WH	SPEAKER/MICROPHONE	SPEAKER	23.JF4J3.001	

H6510BD	SPEAKER/MICROPHONE	SPEAKER	23.JFZJ3.001	
X1140A X1240	MISCELLANEOUS	FOOT ADJUST	47.JERJ3.001	
P1340W/X1340WH H6510BD	MISCELLANEOUS	FOOT ADJUST	47.JF4J3.001	
X1140A X1240	MISCELLANEOUS	RUBBER ADJUST	47.JERJ3.002	
P1340W/X1340WH H6510BD	MISCELLANEOUS	RUBBER ADJUST	47.JF4J3.002	
X1140A X1240 P1340W/X1340WH	MISCELLANEOUS	FILM LAMP EXPLOSION	47.JERJ3.003	
X1140A X1240	MISCELLANEOUS	DUST FILTER	MC.40511.004	
X1140A X1240 P1340W/X1340WH H6510BD	TOOL KIT	TOOL KIT FOR EDID UPLOAD	6K.J900Q.001	

(Note) The updated P/N refers to latest Spare Part List

Appendix A - Code List: IR / RS232 / DDC Data

1. Remote Control Code

IR setting value

Frequency: 38kHz

Protocol: NEC format

b. IR command code


Customer code : 0813

● For X1140A/X1240/X1140: E1 Remote



87	8E		8F
60	8D		8C
8B	61		80
	82		
83	84		81
	85		
5A	5B	5C	5D
65	66	67	9E
5E	4A	4B	5F

● For P1340W/X1340WH: E5 remote



87	8E		8F
60	8D		8C
8B	61		80
	82		
83	84		81
	85		
5A	5B	5C	5D
65	66	67	9E
5E	4A	4B	5F

● For H6510BD: E9 remote



87	8E		8F
60	8D		8C
8B	61		80
	82		
83	84		81
	85		
5A	5B	5C	5D
65	66	67	9E
5E	4A	4B	5F

2. RS-232 Command Code

General command type (Projector 'receives' commands)			
No	Code (character)	Function feature	Note
1	OKOKOKOKOK	Power On	support
2	* 0 IR 001	Power On	support
3	* 0 IR 002	Power Off	support
4	* 0 IR 004	Keystone	support
5	* 0 IR 006	Mute	support
6	* 0 IR 007	Freeze	support
7	* 0 IR 008	Menu	support
8	* 0 IR 009	Up	support
9	* 0 IR 010	Down	support
10	* 0 IR 011	Right	support
11	* 0 IR 012	Left	support
12	* 0 IR 013	Enter	Unsupport
13	* 0 IR 014	Re-Sync	support
14	* 0 IR 015	Source Analog RGB for D-sub	support
15	* 0 IR 016	Source Digital RGB	Unsupport
16	* 0 IR 017	Source PbPr for D-sub	support
17	* 0 IR 018	Source S-Video	support
18	* 0 IR 019	Source Composite Video	support
19	* 0 IR 020	Source Component Video	support (only for H6510BD)
20	* 0 IR 021	Aspect ratio 16:9	support
21	* 0 IR 022	Aspect ratio 4:3	support
22	* 0 IR 023	Volume +	support
23	* 0 IR 024	Volume –	support
24	* 0 IR 025	Brightness	support
25	* 0 IR 026	Contrast	support
26	* 0 IR 027	Color Temperature	support
27	* 0 IR 028	Source Analog RGB for DVI Port	Unsupport
28	* 0 IR 029	Source Analog YPbPr for DVI Port	Unsupport
29	* 0 IR 030	Hide	support
30	* 0 IR 031	Source	support
31	* 0 IR 032	Video: Color saturation adjustment	support
32	* 0 IR 033	Video: Hue adjustment	support
33	* 0 IR 034	Video: Sharpness adjustment	support
34	* 0 IR 035	Query Model name	support
35	* 0 IR 036	Query Native display resolution	support
36	* 0 IR 037	Query company name	support
37	* 0 IR 040	Aspect ratio L.Box	support (for P1340W/X1340WH/H6510BD)
38	* 0 IR 041	Aspect ratio 1:1	Unsupport
39	* 0 IR 042	Keystone Up	support
40	* 0 IR 043	Keystone Down	support
41	* 0 IR 044	Keystone Left	Unsupport
42	* 0 IR 045	Keystone Right	Unsupport
43	* 0 IR 046	Zoom	support

44	* 0 IR 047	e-Key	support
45	* 0 IR 048	Color RGB	support
46	* 0 IR 049	Language	support
47	* 0 IR 050	Source HDMI	support (for P1340W/X1340WH/ H6510BD)
General command type (Projector 'transmits' commands)			
NO	Code (character)	Function feature	Note
1	Model XXXXXXXX	Return the Model name	support
2	Res XXXXX	Return the Native display resolution	support
3	Name XXXXXXXX	Return the company name	support
Lamp command type (Projector 'receives' commands)			
NO	Code (character)	Function feature	Note
1	* 0 Lamp ?	Query the lamp ON/OFF	support
2	* 0 Lamp	Query the lamp hours	support
Lamp command type (Projector 'transmits' commands)			
NO	Code (character)	Function feature	Note
1	Lamp 0	Return Lamp OFF status	support
2	Lamp 1	Return Lamp ON status	support
3	XXXX	Return Lamp hours	support
Source command type (Projector 'receives' commands)			
NO	Code (character)	Function feature	Note
1	* 0 Src ?	Query source input type	support

3. DDC Data

For X1140A/X1240/X1140(Only Dsub DDC):


X1140A	X1240	X1140
Dsub	Dsub	Dsub
00 FF FF FF FF FF FF 00 04 72 27 14 01 00 00 00 14 16 01 03 0E 00 00 78 0A 43 6E A5 57 4F 9D 25 0D 4E 5E 3F CF 80 31 7C 45 7C 61 7C 81 C0 81 00 81 80 95 00 A9 40 A0 0F 20 00 31 58 1C 20 28 80 14 00 00 00 00 00 00 1E 00 00 00 FD 00 30 78 1F 63 11 00 0A 20 20 20 20 20 20 00 00 00 FC 00 58 31 31 34 30 41 0A 20 20 20 20 20 20 00 00 00 FF 00 4A 45 52 31 31 30 30 31 38 34 30 31 0A 00 C6 acer X1140A DSUB	00 FF FF FF FF FF FF 00 04 72 02 15 01 00 00 00 14 16 01 03 0E 00 00 78 0A 43 6E A5 57 4F 9D 25 0D 4E 5E 3F CF 80 31 7C 45 7C 61 7C 81 C0 81 00 81 80 95 00 A9 40 64 19 00 40 41 00 26 30 18 88 36 00 00 00 00 00 00 1C 00 00 00 FD 00 30 78 1F 63 11 00 0A 20 20 20 20 20 20 00 00 00 FC 00 58 31 32 34 30 0A 20 20 20 20 20 20 20 00 00 00 FF 00 4A 46 32 31 31 30 30 32 38 34 30 35 0A 00 4C acer X1240 DSUB	00 FF FF FF FF FF FF 00 04 72 32 15 01 00 00 00 1E 16 01 03 0E 00 00 78 0A 43 6E A5 57 4F 9D 25 0D 4E 5E 3F CF 80 31 7C 45 7C 61 7C 81 C0 81 00 81 80 95 00 A9 40 A0 0F 20 00 31 58 1C 20 28 80 14 00 00 00 00 00 00 1E 00 00 00 FD 00 30 78 1F 63 11 00 0A 20 20 20 20 20 20 00 00 00 FC 00 58 31 31 34 30 0A 20 20 20 20 20 20 20 00 00 00 FF 00 4A 46 57 31 31 30 30 31 38 34 30 31 0A 00 CB X1140 acer DSUB

For P1340W/X1340WH:


P1340W/X1340WH	P1340W/X1340WH
Dsub	HDMI
00 FF FF FF FF FF FF 00	00 FF FF FF FF FF FF 00
04 72 04 15 01 00 00 00	04 72 04 15 01 00 00 00
03 16 01 03 0E 00 00 78	03 16 01 03 80 00 00 78
0A 30 31 A1 5B 56 92 25	0A 30 31 A1 5B 56 92 25
13 4F 5B 3F CF 80 31 7C	13 4F 5B 3F CF 80 31 7C
45 7C 61 7C 81 3C 81 80	45 7C 61 7C 81 3C 81 80
81 C0 95 00 A9 40 9E 20	81 C0 95 00 D1 C0 9E 20
00 90 51 20 1F 30 48 80	00 90 51 20 1F 30 48 80
36 00 00 00 00 00 00 1C	36 00 00 00 00 00 00 1C
00 00 00 FD 00 30 78 1F	00 00 00 FD 00 30 78 1F
63 11 00 0A 20 20 20 20	63 11 00 0A 20 20 20 20
20 20 00 00 00 FC 00 50	20 20 00 00 00 FC 00 50
31 33 34 30 57 0A 20 20	31 33 34 30 57 0A 20 20
20 20 20 20 00 00 00 FF	20 20 20 20 00 00 00 FF
00 4A 46 34 31 31 30 30	00 4A 46 34 31 31 30 30
31 38 34 30 31 0A 00 60	31 38 34 30 31 0A 01 45
6	02 03 2A F1 4C 01 06 02
ACER	15 11 84 13 05 14 10 1F
P1340W	20 23 09 17 07 83 01 00
ADT	00 6C 03 0C 00 10 00 38
A5	28 20 A0 02 01 41 E3 05
ddc2	03 01 01 1D 80 D0 72 1C
	16 20 10 2C 25 80 C4 8E
	21 00 00 9E 01 1D 80 18
	71 1C 16 20 58 2C 25 00
	C4 8E 21 00 00 9E 01 1D
	00 BC 52 D0 1E 20 B8 28
	55 40 C4 8E 21 00 00 1E
	8C 0A A0 14 51 F0 16 00
	26 7C 43 00 13 8E 21 00
	00 B8 00 00 00 00 00 00
	00 00 00 00 00 00 00 26
	6
	ACER
	P1340W
	ADT
	A5
	ddc2

For H6510BD:






H6510BD	H6510BD	H6510BD
Dsub	HDMI1	HDMI2
00 FF FF FF FF FF FF 00	00 FF FF FF FF FF FF 00	00 FF FF FF FF FF FF 00
04 72 35 15 01 00 00 00	04 72 35 15 01 00 00 00	04 72 35 15 01 00 00 00
28 16 01 03 0E 00 00 78	28 16 01 03 80 00 00 78	28 16 01 03 80 00 00 78
0A 43 6E A5 57 4F 9D 25	0A 43 6E A5 57 4F 9D 25	0A 43 6E A5 57 4F 9D 25
0D 4E 5E 3F CF 80 31 7C	0D 4E 5E 3F CF 80 31 7C	0D 4E 5E 3F CF 80 31 7C
45 7C 61 7C 81 3C 81 C0	45 7C 61 7C 81 3C 81 80	45 7C 61 7C 81 3C 81 80
81 80 95 00 A9 40 02 3A	81 C0 95 00 D1 C0 02 3A	81 C0 95 00 D1 C0 02 3A
80 18 71 38 2D 40 58 2C	80 18 71 38 2D 40 58 2C	80 18 71 38 2D 40 58 2C
45 00 00 00 00 00 00 1E	45 00 00 00 00 00 00 1E	45 00 00 00 00 00 00 1E
00 00 00 FD 00 30 78 1F	00 00 00 FD 00 17 78 0F	00 00 00 FD 00 17 78 0F
66 11 00 0A 20 20 20 20	66 11 00 0A 20 20 20 20	66 11 00 0A 20 20 20 20
20 20 00 00 00 FC 00 48	20 20 00 00 00 FC 00 48	20 20 00 00 00 FC 00 48
36 35 31 30 42 44 0A 20	36 35 31 30 42 44 0A 20	36 35 31 30 42 44 0A 20
20 20 20 20 00 00 00 FF	20 20 20 20 00 00 00 FF	20 20 20 20 00 00 00 FF
00 4A 46 5A 31 31 30 30	00 4A 46 5A 31 31 30 30	00 4A 46 5A 31 31 30 30
31 38 34 30 31 0A 00 DD	31 38 34 30 31 0A 01 EB	31 38 34 30 31 0A 01 EB
H6510BD	02 03 29 F1 4D 06 02 15	02 03 29 F1 4D 06 02 15
acer	11 04 13 05 14 90 1F 20	11 04 13 05 14 90 1F 20
DSUB	21 22 23 09 17 07 83 01	21 22 23 09 17 07 83 01
A5E	00 00 6A 03 0C 00 10 00	00 00 6A 03 0C 00 20 00
	38 28 20 80 00 E3 05 03	38 28 20 80 00 E3 05 03
	01 8C 0A D0 8A 20 E0 2D	01 8C 0A D0 8A 20 E0 2D
	10 10 3E 96 00 C4 8E 21	10 10 3E 96 00 C4 8E 21
	00 00 18 01 1D 00 72 51	00 00 18 01 1D 00 72 51
	D0 1E 20 6E 28 55 00 C4	D0 1E 20 6E 28 55 00 C4
	8E 21 00 00 1E 01 1D 80	8E 21 00 00 1E 01 1D 80
	18 71 1C 16 20 58 2C 25	18 71 1C 16 20 58 2C 25
	00 C4 8E 21 00 00 9E F3	00 C4 8E 21 00 00 9E F3
	39 80 18 71 38 2D 40 58	39 80 18 71 38 2D 40 58
	2C 45 00 C4 8E 21 00 00	2C 45 00 C4 8E 21 00 00
	1E 00 00 00 00 00 00 00	1E 00 00 00 00 00 00 00
	00 00 00 00 00 00 00 73	00 00 00 00 00 00 00 63
	H6510BD	H6510BD
	acer	acer
	HDMI1	HDMI2






D-sub RGB Output







RS232 Circuit



















P1340W/X1340WH:






D-sub RGB Output






HDMI INTERFACE






Audio Input/Output Terminal
















KeyPad & LED Circuit













●













KeyPad Circuit




LED Circuit









The resistor value is 0.47Q to 2.2Q
Voltage range for the SENSE is 100-150mV,
at least 80 mV.





Swap Ch:A with Ch:B
Half bus port with bus data bit order swap






Power Board:

● X1140A/X1240/X1140/P1340W/X1340WH:





H6510BD:

